

TERMS AND CONDITIONS OF SALE AND LICENSE OF TANDY COMPUTER EQUIPMENT AND SOFTWARE PURCHASED FROM RADIO SHACK COMPANY-OWNED COMPUTER CENTERS RETAIL STORES AND RADIO SHACK FRANCHISEES OF DEALERS AT THEIR AUTHORIZED LOCATIONS

### LIMITED WARRANTY

### CUSTOMER ORLIGATIONS

- CUSTOMER assumes full responsibility that this computer hardware purchased (the "Equipment"), and any copies of software included with the Equipment or licensed separately (the "Software") meets the specifications, capacity, capabilities, versatility and other requirements of CUSTOMER
- CUSTOMER assumes full responsibility for the condition and effectiveness of the operating environment in which the Equipment and Software are to function, and for its installation

### 35 LIMITED WARRANTIES AND CONDITIONS OF SALE

- For a period of ninety (90) calendar days from the date of the Radio Shack sales document received upon purchase of the Equipment RADIO SHACK warrants to the original CUSTOMER that the Equipment and the medium upon which the Software is stored is free from manufacturing defects. This warranty is only applicable to purchases of Tandy Equipment by the original customer from Radio Shack company-owned computer centers, retail stores, and Radio Shack franchisees and dealers at the authorized locations. The warranty is void if the Equipment's case or cabinet has been opened, or if the Equipment or Software has been subhected to improper or abnormal use. If a manufacturing defect is discovered during the stated warranty period, the defective Equipment must be returned to a Radio Shack Computer Center a Radio Shack retail store, a participating Radio Shack ranchisee or a participating Radio Shack dealer for repair along with a copy or the sales document or lease agreement. The original CUSTOMER'S sole and exclusive remedy in the event or a defect is limited to the correction of the defect by repair, replacement, or refund of the purchase price, at RADIO SHACK'S election and sole avenues. RADIO SHACK san opinitation to replace or repair along the purchase price, at RADIO SHACK'S election and sole avenues. RADIO SHACK has no obligation to replace or repair expendable items.
- expense. RADIO SHACK has no obligation to replace or repair expensable terms.

  RADIO SHACK makes no warranty as to the design, capability capacity, or suitability for use of the Software except as provided in this paragraph. Software is licensed on an "AS IS" basis, without warranty. The original CUSTOMER'S exclusive remedy, in the event of a Software manufacturing defect, is its repair or replacement within flurity (30) calendar days of the date of the Radio Shack sales document received upon license of the Software The orefective Software shall be returned to a Radio Shack Computer Center a Radio Shack sales document store, a participating Radio Shack franchises or Radio Shack dealer along with the sales document. R
- Except as provided herein no employee, agent, franchisee, dealer or other person is authorized to give any warranties of any nature on benefit of RADIO SHACK
- D EXCEPT AS PROVIDED HEREIN, RADIO SHACK MAKES NO EXPRESS WARRANTIES. AND ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE IS LIMITED IN ITS DURATION TO THE DURATION OF THE WRITTEN LIMITED WARRANTIES SET FORTH HEREIN.
- Some states do not allow limitations on how long an implied warranty lasts, so the above limitation(s) may not apply to CUSTOMER

### 111 LIMITATION OF LIABILITY

- EXCEPT AS PROVIDED HEREIN, RADIO SHACK SHALL HAVE NO LIABILITY OR RESPONSIBILITY TO CUSTOMER OR ANY OTHER PERSON OR ENTITY WITH RESPECT TO ANY LIABILITY, LOSS OR DAMAGE CAUSED OR ALLEGED TO BE CAUSED DIRECTLY OR INDIRECTLY BY "EQUIPMENT" OR "SOFTWARE" SOLD. LEASED, LICENSED OR FURNISHED BY RADIO SHACK, INCLUDING, BUT NOT LIMITED TO, ANY INTERRUPTION OF SERVICE, LOSS OF BUSINESS OR ANTICIPATORY PORTS OR CONSCIUENTIAL DAMAGES RESULTING FROM THE USE OR OPERATION OF THE "EQUIPMENT" OR "SOFTWARE." IN NO EVENT SHALL RADIO SHACK BE LIABLE FOR LOSS OF PROFITS, OR ANY INDIRECT SPECIAL, OR CONSEQUENTIAL DAMAGES ARISING OUT OF ANY BRACK OF THIS WARRANTY OR IN ANY MANNER ARISING OUT OF OR CONNECTED WITH THE SALE. LEASE, LICENSE, USE OR ANTICIPATED USE OF THE "EQUIPMENT" OR "SOFTWARE."
  - NOTWITISTANDING THE ABOVE LIMITATIONS AND WARRANTIES, RADIO SHACK'S LIABILITY HEREUNDER FOR DAMAGES INCURRED BY CUSTOMER OR OTHERS SHALL NOT EXCEED THE AMOUNT PAID BY CUSTOMER FOR THE PARTICULAR "EQUIPMENT" OR RADIO SHACK shall not be lable for any damages caused by delay in delivering or furnishing Equipment and or Software
- No action arising out of any claimed breach of this Warranty or transactions under this Warranty may be brought more than two (2) years after the cause of action has accrued or more than four (4) years after the date of the Radio Shack seles document for the Equipment or Software, whichever first occurs,

  Some states do not allow the limitation or exclusion of inoidental or consequential damages, so the above limitation(s) or exclusion(s) may
- not apply to CUSTOMER

### SOFTWARF LICENSE

RADIC SHACK grants to CUSTOMER a non-exclusive paid-up license to use the TANDY Software on one computer, subject to the following provisions


- Except as otherwise provided in this Software License, applicable copyright laws shall apply to the Software B
- Title to the medium on which the Software is recorded (cassette and or diskette) or stored (ROM) is transferred to CUSTOMER, but not tne Software
- CUSTOMER may use Software on one host computer and access that Software through one or more terminals if the Software permits this function Ð
- CUSTOMER shall not use, make, manufacture, or reproduce copies of Software except for use on one computer and as is specifically
- CUSTOMER shall not use, make, manufacture or reproduce copies of Software except for use on one computer and as is specifically provided in this Software License. Customer is expressly prohibited from disassembling the Software for a deditional copies are required customers. It is permitted to make additional copies of the Software only for backup or archival purposes or it additional copies are required in the operation of one computer with the Software, but only to the extent the Software allows a backup copy to be made. However for TRSDOS Software CUSTOMER is permitted to make a limited number of additional copies for CUSTOMER's own use. CUSTOMER may reselt or distribute ownedfied copies of the Software provided CUSTOMER is concased one copy of the Software for each one sold or distributed. The provisions of this Software License shall also be applicable to third parties receiving copies of the Software for CUSTOMER and CUST
- Ġ

### V APPLICABILITY OF WARRANTY

- The terms and conditions of this Warranty are applicable as between RADIO SHACK and CUSTOMER to either a sale of the Equipment and or Software License to CUSTOMER or to a transaction whereby Radio Snack sells or cenveys such Equipment to a third party for lease to CUSTOMER.
- The limitations of liability and Warranty provisions herein shall indire to the benefit of RADIO SHACK, the author lower and or licensor of the Software and any manufacturer of the Equipment sold by Radio Shack

### 121

The warranties granted herein give the original CUSTOMER specific legal rights, and the original CUSTOMER may have other rights which vary



### READ ME FIRST


All computer software is subject to change, correction, or improvement as the manufacturer receives customer comments and experiences. Radio Shack has established a system to keep you immediately informed of any reported problems with this software, and the solutions. We have a customer service network including representatives in many Radio Shack Computer Centers, and a large group in Fort Worth, Texas, to help with any specific errors you may find in your use of the programs. We will also furnish information on any improvements or changes that are "cut in" on later production versions.

To take advantage of these services, you must do three things:

- (1) Send in the postage-paid software registration card included in this manual immediately. (Postage must be affixed in Canada.)
- (2) If you change your address, you must send us a change of address card (enclosed), listing your old address exactly as it is currently on file with us.
- (3) As we furnish updates or "patches", and you update your software, you must keep an accurate record of the current version numbers on the logs below. (The version number will be furnished with each update.)

Keep this card in your manual at all times, and refer to the current version numbers when requesting information or help from us. Thank you.

APPL	ICATIONS SOFT VERSION LOG	WARE	OP. SYSTEM VERSION LOG
81.00 · 3			
		West of the Park Control o	
		***************************************	
		***************************************	




### ATTENTION: ALL MODEL 4/4P USERS

Whenever you change diskettes in Drive  $\emptyset$ , you must press RESET if the diskettes contain different versions of the operating system. If you do not press RESET, data on your diskette may be damaged.

A change from 6.1.2 to 6.2.x requires RESET.

A change from 6.2.0 to 6.2.1 (or vice versa) does not require RESET.

Radio Shack A Division of Tandy Corporation



Ù
0
9
Ë
O

# Name \_\_\_\_\_ Company \_\_\_\_\_ Address City \_\_\_\_\_ Phone ( ) \_\_\_\_ - \_\_\_\_ State \_\_\_\_\_ Zip \_\_\_\_

Name \_\_\_\_\_\_ Company \_\_\_\_\_ Address City \_\_\_\_\_ Phone ( ) \_\_\_\_ - \_\_\_\_ State \_\_\_\_\_ Zip \_\_\_\_

# Name \_\_\_\_\_ Company Address City \_\_\_\_\_ Phone ( ) \_\_\_\_ - \_\_\_\_ State \_\_\_\_\_Zip \_\_\_\_

Company \_\_\_\_\_ Address City \_\_\_\_\_ Phone ( ) \_\_\_\_ - \_\_\_\_ State Zip

Name \_\_\_\_\_

PLACE STAMP HERE

Software Registration Data Processing Dept. P.O. Box 2910 Fort Worth, Texas 76113-9965

> PLACE STAMP HERE

Software Registration Data Processing Dept. P.O. Box 2910 Fort Worth, Texas 76113-9965

# ADDENDUM TO DeskMate™REFERENCE MANUAL DeskMate™SAMPLE SESSION

Cat. No. 26-1608

Please make the following changes to your DeskMate manuals.


### Sample Session

page 46 The printout of the sample worksheet will not exactly match your printout of the worksheet. Some of the figures will differ by 1 cent.

### Reference Manual

- page 66 FILER Form Functions. The warning notice for efficiency D is not currently implemented on the Main Filer Screen. It is recommended that you use the FORM function on a regular basis to check the efficiency level.
- page 79 TELECOM Terminal Receive. The RECEIVE function may lose characters when transmitting at baud rates greater than 1200. If you transmit at higher speeds, capture characters into the RAM buffer (using CLEAR 0), then SAVE the RAM buffer to the diskette after transmission is complete.
- page 93 MAIL Help Screens. The Mail application contains only 1 help screen.
- page 96 MAIL Create. A message description can contain a maximum of 32 characters.
- page 163 APPENDIX B MODEM INFORMATION Modem II. In the Answer Mode definition, delete the last line, "RECEIVE X."
- page 164 APPENDIX B MODEM INFORMATION DC-2212. In the Voice Dialing definition, additional pauses may be necessary when dialing a long telephone number.
- page 166 APPENDIX C HARD DISK INSTRUCTIONS. In Step 5, there should be no space between "SET" and "KI." Change the first part of this entry to "SETKI."

Radio Shack A Division of Tandy Corporation



# **DeskMate**<sup>™</sup> Reference Manual

DeskMate™ Software: © 1985 Tandy Corporation. All Rights Reserved.

All portions of this software are copyrighted and are the proprietary and trade secret information of Tandy Corporation. Use, reproduction, or publication of any portion of this material without prior written authorization by Tandy Corporation is strictly prohibited.

DeskMate<sup>™</sup> Reference Manual: ©1985 Tandy Corporation. All Rights Reserved.

Reproduction or use, without prior written authorization by Tandy Corporation, of any portion of this documentation is prohibited. While reasonable efforts have been taken to assure its accuracy, Tandy Corporation assumes no liability resulting from any errors in or omissions from this manual or from the use of the information contained herein.

Tandy, TRSDOS, and TRS-80 are Registered Trademarks and DeskMate is a Trademark of Tandy Corporation.

CompuServe is a Registered Trademark of CompuServe, Inc.

Dow Jones and Dow Jones News/Retrieval are Registered Trademarks of Dow Jones & Co., Inc.

10 9 8 7 6 5 4 3 2 1

# Contents

1	DeskMate Overview	1
	Introduction	1
	Entering DeskMate	3
	Key Usage	4
	Files and Operations	6
	Creating or Opening an Application File	6
	Exiting an Application File	7
	Canceling an Operation	7
	DeskMate Subfunctions	8
	Help	8
	Alarm	9
	Calculator	9
	Phone	11
	Phone Functions	12
	Screen	13
	Printer	14
	Date	15
	Alarm On/Off	15
2	Main Menu	17
	Main Menu Overview	17
	Help Screens	17
	Main Menu Functions	18
	Date	18
	Name	18
	Free	18
	Alarm	19
	Help Screens	19
	Adding Events	19
	Arrow Keys	20
	Deleting Events	21
	Alarm Functions	21
	Host	22
	Setting the Modern and Switches	22
	Local Operation	23
	Remote Site Setup	24
	Remote Site Operation	24
	Passwd	29
	Select	29
	Copy	30
	Delete	30
	Swap	30

3	Text		31
		Text Overview	31
		Help Screens	31
		Using Text	32
		Typing and Editing a Document	32
		Defining and Manipulating Blocks of Text	32
		The Arrow Keys	34
		Printing a Document	34
		Text Functions	35
		Find	35
		Print	35
		Add/Replace	36
		Format	36
		Merge	36
		Save	37
		Select	37
		Copy	38
		Delete	39
		Insert	39
		Exchange	39
4	Worl	ksheet	41
		Worksheet Overview	41
		Help Screens	41
		The Worksheet	42
		Arrow Keys	44
		Setting Up a Worksheet	45
		Adding Data to a Worksheet	45
		Performing Calculations	47
		Worksheet Functions	48
		Find	48
		Calc	48
		Formula	49
		Text	53
		Format	53
		Merge	54
		Select	55
		Copy	55
		Delete	55
		Insert	56
		Print	56
		Outcomes	56

5	Filer	57
	Filer Overview	57
	Help Screens	57
	Using Filer	58
	Setting Up a Form	58
	Adding Records	59
	Arrow Keys	60
	Printing Records	61
	Filer Functions	62
	Find	62
	Call	63
	Display	63
	Print	64
	Form	64
	Defining a Label	65
	Defining a Field Area	65
	Form Functions	66
	Merge	67
	Select	68
	Сору	68
	Delete	68
	Add	69
6	Telecom	71
	Telecom Overview	71
	Help Screens	71
	Setting the Status	71
	Telecom Functions	74
	Reset	74
	Select	74
	Comp	74
	Voice	75
	Answer	76
	Autolog	77
	Editlog	77
	Terminal	79
	Display	80
	Print	80
	Save	81
	Load	81
	Clear	Ω1

7	Calendar	83
	Calendar Overview	83
	Help Screens	83
	Using Calendar	84
	Adding Events	84
	Defining and Manipulating Event Blocks	85
	Arrow Keys	86
	Printing a List of Events	87
	Calendar Functions	88
	Find	88
	Date	89
	Print	89
	Alarm	90
	Merge	90
	Select	91
	Сору	91
	Delete	91
	Add	92
0		00
8	Mail	93
	Mail Overview	93
	Help Screens	93
	Using Mail	94
	Adding Messages	94
	Arrow Keys	95
	Printing Messages	95
	Mail Functions	96
	Find	96
	Create	96
	Display	97
	Print	97
	Delete	97
	11	0.0
$\mathbf{A}_{\mathbf{I}}$	ppendices	99
	A Backup Procedures	99
	B Modem Information	
	C Hard Disk Instructions	105
	,	
ir	ndex	$\pm 107$

### INTRODUCTION

DeskMate is an integrated, easy-to-use set of applications and functions that conserve time, energy, and space. These applications replace many of your manual production tools: typewriter, calculator, rolodex, calendar, notepad, and so forth. All applications in the system use similar functions and operations, which makes DeskMate easy to learn and use.

Using DeskMate not only is faster than using your manual tools, but also allows easy access for updates and corrections. Information may be added to, deleted from, or duplicated in files quickly and easily. Also, many applications provide "at-a-glance" information for quick decision making or question answering. All DeskMate information may be displayed on the screen or printed.

DeskMate consists of ten Main Menu functions, eight "subfunctions," and six major applications along with their individual functions. Separate chapters of this reference manual explain in-depth each of the major applications and their functions. The Main Menu functions are also presented in a separate chapter. The DeskMate Overview details the subfunctions.

Following is a brief description of the DeskMate applications.

- TEXT is a text editor, in which you can create, review and edit, and print documents.
- WORKSHEET lets you compute numbers in columns and rows.
   Addition, subtraction, multiplication, division, exponentiation, as well as other set, statistical, and trigonometric operations are available.
- FILER is a card file type filing system. Any number of "forms" of information may be stored. An item may be filed and searched for by any of the information contained therein.
- TELECOM acts as a telecommunications terminal. DeskMate goes into an interactive terminal mode so that information may be transmitted from another system.

- CALENDAR is an event scheduling system. Recorded events may be reviewed at any time. A list of the events for the day displays at the Main Menu.
- MAIL is a messaging system. Messages are created and stored in the system in files according to whom they were written. General information messages can go into a common file, MESSAGES.

Additionally, the ALARM and HOST functions on the Main Menu, and the CALCULATOR and PHONE subfunctions should be mentioned here.

- ALARM is an event reminder system. An alarm may be set for certain events. Events may be entered directly into the ALARM file, or they may be duplicated from a CALENDAR file.
- HOST is a telecommunications mode for using DeskMate at a remote site. Local operation is locked out while a remote terminal accesses the system.
- CALCULATOR is a quick-access function for simple addition, subtraction, multiplication, division, and percentage calculations.
- PHONE lets you store, review, and call (with an automatic dialing modem) phone numbers. Initials and names identify each number.

### Notes On Hardware Requirements

DeskMate is completely self-sufficient. Your computer and the DeskMate software are all that is required to run the basic system. A modem is required to communicate with another computer using TELECOM or HOST. To use the automatic logon feature of TELECOM or HOST, or the dialing feature of PHONE, the modem must be programmable (automatic dialing). Check the operating instructions of your modem for details.

Additionally, a printer is helpful for producing permanent records of DeskMate tasks accomplished and information stored.

### ENTERING DESKMATE

At TRSDOS Ready, type DM (ENTER). The Main Menu displays:

3 4 1Ø 11 1 17 18 1	FEB 19	1 2 7 8 9 4 15 16 1 22 23	Ø5:30a 07:30a 08:30a	for To Make Mam' Writ Shop Meet Prep	appoint s birthd e confir	ay ca mation l and pro gym for Dav	h accour ll flori etter to duce who	ntant st Wilson Dlesale r	10:30am markets
Text	D	Workshee BUDGET		ler ENTS	Tele	COM	Calenda AGENDA	L	Mail AURA ESSAGES
[Ø] DATE	[1] NAME	[2] FREE	[3] ALARM	[4]	[5] PASSWD	[6] SELECT	[7] COPY	[8]	[9] SWAP

At the top left of the Main Menu is a calendar for the current month. Today's date (the current system date) is highlighted. The next seven Events for Today, ALARM events for which the Remind @ time has not yet passed, display at the top right. The applications display between the two solid horizontal bars, on the application name line. Below each application are its corresponding data files. The last two lines, the function label lines, display the Main Menu function names and numbers. (Label lines appear in each application, showing the functions specific to that application.)

### **KEY USAGE**

Key usage is very similar throughout the system. There are three types of keys in the DeskMate: command keys, arrow keys, and function keys. Following are key descriptions.

The DeskMate command keys, (F1), (F2), (F3), (SHIFT) (F3), and (BREAK), are used throughout DeskMate to perform a system function. Command key operation is described in Table 1.

<b>F1</b> )	BACKSPACEs; deletes the character over which it backspaces (the character immediately in front of the marker)
<b>F2</b>	displays the DeskMate subfunctions
<b>F3</b>	saves all data and settings entered in the current file and RETURNs to the previous operation; exits to TRSDOS from the Main Menu
SHIFT F3	CANCELs changes to the current line and changes to the settings and returns to the Main Menu; exits to TRSDOS from the Main Menu
BREAK	BREAKs (cancels) the current request, prompt, or command
	Table 1. Command Key Operation.

The arrow keys, T, T, and (alone, with SHIFT), and with CLEAR), are used throughout DeskMate to move the marker and display specific application information. Arrow key usage varies slightly in each application; see the appropriate application chapter for specific usage. General arrow key usage is described in Table 2.

	moves the marker to the previous line
	moves the marker to the next line
<u>-</u>	moves the marker to the left one position
$\overline{}$	moves the marker to the right one position
SHIFT 1	moves the marker to the top line of the screen
SHIFT (	moves the marker to the bottom line of the screen
SHIFT (-	moves the marker to the left margin of the screen
SHIFT -	moves the marker to the right margin of the screen
CLEAR (1)	displays the first item in the file
CLEAR (	displays the last item in the file
CLEAR —	displays the previous item in the file
CLEAR -	displays the next item in the file

Table 2. General Arrow Key Usage.

Function keys are specific to each application. With the exception of the TEXT EXCHANGE and the WORKSHEET PRINT and OUTCOMES functions (CLEAR) (E), CLEAR) (P), and CLEAR) (O), respectively), functions are represented by a number. Function numbers and names display on the last two lines of the application screens. Hold down the CLEAR key, and press the appropriate number to use a function.

## FILES AND OPERATIONS

# Creating or Opening an Application File

To create a new file for an application, use the left and right arrow keys to place the marker over the application name (between the two solid horizontal bars) on the Main Menu. (SHIFT) with — or — moves the marker to the leftmost or rightmost application name.) Press (ENTER).

For all applications except TELECOM and MAIL, you are prompted to enter a filename. Type a name for the new file, and press (ENTER). A valid filename begins with a letter, contains no spaces, and is no more than eight characters in length. Do not add a file extension (/DOC, and so forth). DeskMate automatically adds the proper file extension when it creates a file.

You may also press (BREAK) at the filename prompt. Pressing (BREAK) to override the filename enters the application without creating a file in which to save data. This lets you use the DeskMate applications as a "scratchpad." Everything you calculate or record is erased as soon as you exit the application.

The TELECOM and MAIL applications may be opened directly from the application name line. TELECOM uses data files only to store auto logon sequences. The Current Status screen appears when you open the TELECOM application. MAIL uses data files, including a default file for general messages. It is the default file (MESSAGES) that displays when you select MAIL from the application name line.

You may also open any existing application data file directly. Press to move the marker to the data file listing near the bottom of the screen. Data files appear directly under the application to which they correspond.

Use the arrow keys to move the marker to the desired data file. SHIFT with — or — moves the marker to the leftmost or rightmost data file, respectively. — moves the marker to the next data file in a column, and SHIFT — moves the marker to the last data file on the screen in the current column. If there are more than 10 data files for an application (noted by an asterisk on the bottom line, next to the tenth filename), SHIFT — scrolls to the next screen of data file names. Press ENTER. The first screen in the appropriate application for the data file under the marker appears. Review, edit, or perform other available functions on the information in the data file.

# Exiting an Application File

Press **F3** to exit and close an application file and return to the Main Menu. Press **F3** at the Main Menu to go to TRSDOS Ready.

# Canceling an Operation

Press (BREAK) to cancel the current request, prompt, or command.

Press **SHIFT F3** to CANCEL an operation or application and return to the Main Menu. Press **Y** at Cancel update (Y/N)? Entries and changes that are not already written to the file are not saved. Press **N** at Cancel update (Y/N)? to return to the operation or application.

# DESKMATE SUBFUNCTIONS

The DeskMate subfunctions are simple, easily accessible functions that are available throughout DeskMate, in all applications and at the Main Menu. The subfunctions display information (HELP, ALARM, PHONE), set the printer or print whatever is currently on the screen (PRINTER, SCREEN), perform simple calculations (CALC), dial a telephone number if the system is equipped with an automatic dialing modem (PHONE), and change certain system settings (DATE, ALARM OFF/ON).

Press **F2** to access the subfunctions from the current application or Main Menu. The subfunctions label lines replace the application or Main Menu label lines:

[Ø]-	[1]	[2]	[3]	[4]	[5]	[6]	[7]	[8]	[9]
HELP	ALARM	CALC	PHONE	SCREEN	PRINTER	DATE	ALARM	OFF	

To use a subfunction, hold down the CLEAR key, and press the appropriate function number. Press (F3) to RETURN to the current application after you complete the subfunction. The application returns to the exact point at which you left it.

### Help

Press CLEAR ① at the subfunctions to display HELP (reference information) for the current application. HELP for the current mode (FIND, FORMAT, and FORMULA) or application (if no mode is in use) displays. If there is another HELP screen for an application, the screen shows:

Press Enter to Continue

Press **ENTER** to display each successive HELP screen. The following message displays on the last HELP screen:

Press F3 to Return

Press (3) to exit the HELP subfunction and continue with the current application.

### Alarm

Press (CLEAR) 1 at the subfunctions to display ALARM event information. The application label lines are replaced with the last event for which an alarm has sounded and the next ALARM event.

See the "ALARM" section in Chapter 2 for information on entering events into the ALARM file.

Press (F3) to exit the ALARM subfunction, and continue with the current application.

### Calculator

Press (CLEAR) (2) at the subfunctions to display the CALCULATOR:

[Ø]	[1]	[2]	[3]	[4]	[5]	[6]	[7]	# 9.9
ADD	SUBTR	MULT	DIV	PERCENT	+/-	CA	CE	
								1

CALCULATOR uses a 10-digit display (no commas), floating decimal point format.  $\pm 9,999,999,999$  is the largest number you can enter or accumulate, and  $\pm 0.0000000001$  is the smallest. If the accumulator overflows, it fills with asterisks.

To perform a calculation, type the first number, or operand, in the "entry" (bottom) line. Each numeral pushes the number you are typing one character to the left. (Press (CLEAR) (5) to reverse the sign of the number you type; 10 becomes -10, and so forth. A minus sign displays in front of a negative number.)

The default operator is + (ADD); simply press (ENTER) to add the amount you typed in the entry line to the amount  $(\emptyset.\emptyset)$  in the "accumulator" (top) line. Type a logical operator (+, -, \*, or /), or press (CLEAR) and an operator function number  $(\emptyset-4)$  to perform an operation other than ADD. The functions and operators are as follow:

CLEAR ① or + for addition

CLEAR ① or - for subtraction

CLEAR ② or \* for multiplication

CLEAR ③ or / for division

CLEAR ④ or % for a percent

CLEAR ⑤ to reverse the sign of the operand

CLEAR ⑥ to clear entry (operand)

CLEAR ⑦ to clear all amounts

Note: A percent is: Accumulated amount \* (operand amount/100). For example, to calculate 20% of the accumulator, type 20 as the operand, press (CLEAR) (4) or % to display a percent sign, then press (ENTER).

Type the logical operator, or use the operator function, at any time before you press (ENTER) to calculate the result. The calculated result displays on the accumulator line.

Enter new operands, changing the operator when necessary, until you complete your calculations.

Press **[3]** to exit CALCULATOR and continue with the current application.

### **Phone**

Use PHONE to record and quickly look up phone numbers. With an automatic dialing modem, DeskMate dials the number for you. Press CLEAR 3 at the subfunctions. The screen shows:

```
ABC ABC Exterminators.... 817-99Ø-1212 * ...
AL. Arnold's Liquors.... 817-764-1892 *
CB. Beauchamp, Cindy..... 817-883-1267 * ...
FD. Davis, Frederick..... 817-256-9Ø11 * ...
JH. Helmer, John...... 817-653-8754 * ...
BJ. Jones, Bill...... 817-555-8060 * ...
LFB LaFrance Bakery..... 817-732-5766 * ...
RM. Miller, Robert..... 214-872-4432 * ...
LM. Moore, Lisa (CPA).... 817-832-3358 * ...
PLS Petta Linen Service.. 817-482-7371 * ...
RF. Riverdale Florist.... 817-537-Ø9Ø6 * ...
LR. Roach, Lewis...... 214-872-6680 * ...
CS Sims, Chris...... 817-449-8442 * ...
S&P Smith & Patterson... 214-335-4285 * ...
EW. Williams, Mrs. Eliot. 817-737-7728 * ...
IW. Wordsworth, Laura... 817-921-8831 *
YFM Young's Fish Market.. 817-563-2199 *
                 PREFIX 2: 5551290P..
                                    PREFIX 3: 8559Ø12...
                                                       ACODE: 817
                                                    [8]
[Ø]
             [2]
                          [4] [5]
    [11]
                  [3]
                                      [6]
                                                           191
             PREFIX1 PREFIX2 PREFIX3 SORT PRINT
                                                    DELETE
                                                          ADD
```

There are 39 lines for entry of numbers into the PHONE file. On a blank phone line, type up to 3 characters by which you wish to reference a number (for quick look-up), and press **ENTER**). Next, type up to 21 characters for the name (*lastname*, *firstname* if you want to SORT them), and press **ENTER**). Now, type the area code and telephone number in 999-999-9999 format, and press **ENTER**).

(SHIFT) — and (SHIFT) — move the marker back and forth between the columns.

**Note:** When automatically dialing, PHONE assumes the number is a local one if no area code is entered for it, or if the area code matches ACODE at the bottom right of the screen.

Press CLEAR 1 from anywhere on the screen to move the marker to the PREFIX and ACODE line at the bottom of the screen.

**PREFIX1 - 3** are for entering special codes that precede phone numbers when auto-dialing. Examples of these may be codes for getting an outside line on a PBX system, long distance codes, or access codes to other phone networks. Include a capital letter "P" after the prefix to indicate a 1 second pause.

Any or all of the PREFIX fields can be selected for dialing by pressing CLEAR and the appropriate function number (2, 3, or 4) for the prefix.

**ACODE** is for entering the local area code. When a number is automatically dialed, it is checked for an area code. If there is no area code, or if the area code matches the local area code, it is not dialed. Only area codes out of the local area are dialed.

**Note:** To automatically dial a number, you must previously have defined the Voice Dialing sequence in the TELECOM application. See the TELECOM chapter for details.

### **Phone Functions**

The PHONE functions display at the bottom of the screen. To use a function, hold down (CLEAR), and press the number for the desired function. Special PHONE functions are:

FIND

Use FIND to search for a specific phone number. Press CLEAR throw anywhere on the screen to move the marker to the FIND line. Type the characters for which you wish to search, and press CLEAR ①. (No distinction is made between uppercase and lowercase.) If any matching characters in a reference or name field are found, the marker moves to the matching phone line. Press CLEAR ② again for the next occurrence.

CALL

Press CLEAR 1 to CALL (dial) the telephone number under the marker. If you do not have an automatic dialing modem, or if the number is invalid, the request is ignored. Any PREFIX codes entered and selected (using CLEAR 2 3, or 4) are dialed, in 1, 2, 3 order. The area code is dialed if it is different from ACODE.

Wait a few seconds for dialing to complete, then pick up the phone receiver. (Rotary phones make clicking sounds as they are dialing.) Refer to your modem instruction manual for more information.

PREFIX1

Press **CLEAR 2** to select PREFIX1 for automatic dialing. (Press **CLEAR**) **2** again if you don't want PREFIX1 dialed.)

PREFIX2 Press CLEAR 3 to select PREFIX2 for automatic dialing. (Press CLEAR 3 again if you don't want PREFIX2 dialed.)

PREFIX3 Press **CLEAR 4** to select PREFIX3 for automatic dialing. (Press **CLEAR**) **4** if you don't want PREFIX3 dialed.)

Press **CLEAR 5** to sort all phone entries in alphabetical order, by name.

PRINT Press **CLEAR 6** to print the phone list.

DELETE Press (CLEAR) (8) to delete the phone entry line under the marker.

ADD Press **CLEAR 9** to display a blank entry line at the current marker location for adding a new phone number. Add new phone number lines the same way you first enter numbers into the file.

Press (**F3**) to exit PHONE and continue with the current application.

### Screen

Use SCREEN to print the current screen. First check the PRINTER settings (as explained in the next paragraph) and make sure the Printed Line Width is set to 80. Press (CLEAR) (4) at the subfunctions to print a copy of everything currently on the screen. After the screen prints, the application or Main Menu screen reappears.

### Printer

Use PRINTER to set up your printer for all DeskMate PRINT functions. Press (CLEAR) (5) at the subfunctions. The screen displays the current printer settings. Enter new values for each, or press (ENTER) to use the current value, as follows:

Left Margin: 0

Enter the number of spaces you want from the left edge of the paper to the left margin (the column in which to begin printing).

Printed Line Width: 70

Enter the number of characters that you want to print on one line of your paper, up to the column width of your printer. For example, although an  $8\frac{1}{2}$ " page is 85 characters wide (10 characters per inch), many printers can print only 80 columns. Therefore, on an 80 column printer, 80 is the maximum line width.

Total Lines per Page: 66

Enter the length, in print lines, of the paper. Standard paper is 11" long; normal line spacing produces 6 lines per inch. Therefore, an 11" long paper has 66 lines per page.

Printed Lines per Page: 60

Enter the maximum number of lines to print on a page. The standard is 60, which leaves 6 lines available for top and bottom margins (66 total lines - 60 printed lines). Adjust the paper in the printer to produce the correct top and bottom margins. For example, align the paper at the fourth line down from the top edge in order to leave top and bottom margins of 3 lines each.

Pause between Pages (Y/N): Y

Press (ENTER) to default to Y for single-sheet forms (pause after each page to insert another sheet of paper). Enter N for continuous forms.

After the last prompt, the application or Main Menu screen reappears.

### Date

Use DATE to change the system date and time. Press **CLEAR 6** at the subfunctions. On the date and time line, type the new date (for example, 092284 for September 22, 1984), then the new time (for example, 0245p for 2:45 p.m.), and press **ENTER**).

Note that if you change the date using the DATE subfunction while at the Main Menu, the monthly calendar does not change until you use an application, then return to the Main Menu. To properly update the monthly calendar, change the date with the DATE function on the Main Menu.

### Alarm On/Off

Use ALARM ON/OFF to switch on and off the alarm. Note that this subfunction is not the same as ALARM (Subfunction 1), in which you display the last and next ALARM event. Also note that you enter events in the ALARM function on the Main Menu, and you cannot turn on or off the alarm while in the ALARM function.

ALARM ON/OFF must be ON in order for the alarm to sound. When the ALARM is OFF, no signal of ALARM events is given.

Press (CLEAR) (7) at the subfunctions to change the ALARM status. An asterisk appears next to the date and time on the Main Menu and application screens to indicate that the alarm is on.



# MAIN MENU OVERVIEW

The Main Menu provides access to the applications. In addition, the Main Menu provides functions for making certain system changes (DATE, NAME, SELECT, COPY, DELETE, SWAP), displaying information (FREE), assigning a PASSWORD, and accessing the ALARM and HOST functions.

### Help Screens

The Main Menu HELP screens contain brief summaries of the functions and ways to use them. When the Main Menu is displayed, press **F2** for the subfunctions. Then, press **CLEAR (0)**. After the first HELP screen displays, press **(ENTER)** for the second screen. **(F3)** returns to the Main Menu.

## MAIN MENU FUNCTIONS

Press  $\overline{\text{CLEAR}}$  and the appropriate function number to use a Main Menu function, as follows:

### Date

Use DATE to change the system date and/or time. Press (CLEAR) (0) to display a date and time line. Type the new date, the new time, including a or p for a.m. or p.m., then press (ENTER).

### Name

Use NAME to change the name of a data file. With the marker on the data file you want to change, press (CLEAR) 1. The screen shows:

Enter NEW Filename: oldfile

Type the new filename, and press **ENTER**.

If you do not have the marker on a data file, first enter the name of the data file you want to rename at the Enter OLD Filename prompt. Then, enter the NEW filename.

### Free

Press **CLEAR 2** to display the amount of FREE space (in bytes) on the Data diskette. (SWAP defines which drive contains the Data diskette.) Press any key to continue.

### Alarm

Press (CLEAR) (3) to display the ALARM function. ALARM lets you enter and set a timer for events of which you wish to be reminded. When the ALARM is turned ON (Subfunction 7 — press (F2) to access the subfunctions), it "beeps" three times to signal the occurrence of an event. The alarm sounds regardless of the application you are using. You may also, at any time, display the last and next alarm events (Subfunction 1). You may merge CALENDAR events into the ALARM file, or add events directly to it. ALARM events display in Events for Today on the Main Menu.

### Help Screens

The two ALARM HELP screens contain brief summaries of the functions and ways to use them. Within the ALARM function, press (F2) for the subfunctions. Then, press (CLEAR) (10). After the first HELP screen displays, press (ENTER) for the second screen. (F3) returns to the ALARM screen.

### **Adding Events**

ALARM is always in the edit (overstrike) mode; each character replaces the character at the current marker position. Blank entry lines display when you open the ALARM file for the first time. Add an event simply by entering the appropriate data for each line.

After an ALARM file contains events, the screen displays the events, beginning with the current date, each time you open the file. To add an event to the ALARM file, use the ADD function (CLEAR) 9). Enter event data as follows:

Enter the time at which you want to be reminded of the event (REMIND@ time) in 12-hour, 00:00x format. For example, type 1130a (ENTER) to set the ALARM at 30 minutes before noon.

**Note:** Remember that setting the REMIND@ time **does not** turn on the alarm. Turn on the alarm using ALARM ON/OFF.

Enter the DATE of the event in mm/dd/yyyy format. For example, type 10/22/1984 (ENTER) for October 22, 1984.

Enter the time at which the event BEGINs in 12-hour, 00:00x format. For example, type 1200p (ENTER) for noon.

Enter the time (12-hour) at which the event ENDs in 00:00x format. For example, type 0130p (ENTER) for half past one.

Enter a DESCRIPTION of up to 44 characters for the event. (No uppercase/lowercase distinctions are made in searches for events. **MEETING** and **meeting** are equal.)

After you enter the description, the events automatically sort in DATE/TIME order (regardless of the order in which they are added).

#### **Arrow Keys**

Up to twenty event lines may display on the screen at one time. After you complete the twentieth line, the screen "scrolls," or moves up line by line, so that you may continue. To see a line after it has scrolled off the screen, press until the line appears. Press to return to the line you were typing or editing.

Use the arrow keys to move the marker a character or line at a time. Pressing **SHIFT** or **CLEAR** along with the arrow keys moves the marker more rapidly. See Table 3.

Key	by itself	with (SHIFT) moves the marker:	with CLEAR
$\overline{\Box}$	one character to the right	to the beginning of the first field to the right	Not used
<b>—</b>	one character to the left	to the beginning of the first field to the loft	Not used
<b></b>	one line up in the current column	to the first event line on the screen	to the beginning of the file
	one line down in the current column	to the last event line on the screen	to the end of the file

Table 3. ALARM Marker Movement Keys

#### **Deleting Events**

To delete a block of events, select the first event in the block by pressing <code>CLEAR</code> <code>6</code>. Position the marker on the last event in the block, then press <code>CLEAR</code> <code>8</code>. The highlighted (selected) text block is deleted. If no events are selected, <code>CLEAR</code> <code>8</code> deletes the event under the marker.

Old events, those for which the date and time have already passed, are automatically deleted in order to maintain efficiency in the ALARM file. (You must manually delete the Sample Session data.)

#### **Alarm Functions**

The ALARM functions display at the bottom of the screen. To use a function, hold down the **CLEAR** key, and press the number for the desired function.

MERGE

Press **CLEAR 5** to MERGE a specific CALENDAR file into the ALARM file. The following prompt appears:

Merge from:

Enter the name of the CALENDAR file to merge into this file. The filename and Merging files appears. After the merge is completed, copies of all events in the specified CALENDAR file appear in the ALARM file. The REMIND@ time is set to 30 minutes prior to the BEGIN time for each event.

SELECT

Use SELECT to define an event or a block of events in order to perform some other operation on it. Place the marker on the first event line for inclusion in the block, and press (CLEAR) (6). Use the arrow keys to place the marker over the last event for the block. All selected events are highlighted as you move the marker.

After you select the events, COPY or DELETE them, as appropriate. Press (BREAK) if you decide not to use the selected events. If you use any other function or exit ALARM before you COPY or DELETE, the events are unselected.

COPY

Press **CLEAR 7** to duplicate a selected event block in a document (TEXT application) file on diskette. Press **CLEAR 7** again. Copy to: appears.

Enter the name of the diskette file in which you wish to store the contents of the copy buffer (the selected events). The events are appended to the document file.

DELETE

Press **CLEAR 8** to delete all selected events. The events are immediately deleted. If no events are selected, **CLEAR 8** deletes the event line under the marker.

ADD

Press **CLEAR 9** to display a blank line for adding a new event. Type the data (REMIND@ time, DATE, BEGIN and END times, and DESCRIPTION) for the event you wish to add; press **ENTER** after completing each field.

## Host

HOST allows communication between your computer, as Host, and another computer, such as the Model 100, as a terminal. At the remote site, you can receive a file from the host DeskMate, create a file and send it to the host, and create and read messages in DeskMate MAIL files.

Depending on the capabilities of the remote terminal, you may be able to perform more sophisticated operations. Refer to your terminal's operating instructions. If your remote site is another DeskMate, you can perform any of the operations available in TELECOM while in the Host mode. (See "TELECOM" for more information.)

## Setting the Modem Status and Switches

Before you use HOST, set the communication parameters on the Status screen in the TELECOM application. Also define the Answer Mode (SELECT on the Status screen, then ANSWER) in TELECOM. Refer to the TELECOM chapter for details.

Generally speaking, at the host, modem switches should be set as follows: POWER ON, ANSWER, AUTO (auto-dial), and TEST OFF. Refer to the more specific instructions for modem definition in Appendix B.


#### **Local Operation**

After the host modem is properly connected and set and the communication parameters are set, press (CLEAR) (4) to enter the Host mode from the Main Menu. The screen shows:

Do you want security?

In the normal Host mode, all remote activity echoes (displays) on the DeskMate screen. You may also use HOST in a security mode, in which none of the remote activity echoes to the host. (To exit the Host security mode, you must enter the system password, if one exists.)

Press N for normal Host mode or Y for the security HOST mode. The HOST screen displays:



Press **ENTER** twice to establish communication between your remote terminal and the host, DeskMate.

DeskMate is now ready for access by the remote site. No other local activity is allowed in HOST.

To exit HOST at DeskMate, press (BREAK). If a system password exists and HOST is in the security mode, enter the password. (Note that the password never echoes to the screen.) The Main Menu returns.

#### Remote Site Setup

Properly connect the modem at the remote site. Next, set the remote site modem status and communication parameters, using the remote's Terminal software and/or modem switches. Generally, at the remote site, all modem settings and parameters should be the same as at the host, except for the modem's ORIGINATE/ANSWER switch. Set this switch to ORIGINATE at the remote site.

#### Example:

For a Model 100, using the built-in modem, the settings are:

BAUD RATE = M (built-in modem)

WORD LENGTH = 8

PARITY = N (none)

STOP BIT = 1

LINE STATUS = D (disable — XOFF)

PULSE RATE = 10pps

Follow the instructions for the remote site's Terminal software and modem. Also, refer to the more specific instructions for modem definition in Appendix B.

## Remote Site Operation

Enter the interactive terminal mode, or display the proper screen for connecting with a host computer. Dial (or auto-dial, if so equipped) the number of the telephone line to which the host (DeskMate) is connected

#### Example:

For a Model 100, at the Model 100 TELECOM Entry screen, FIND (or type) the number, then CALL it.

Press  $(\hbox{\tt ENTER})$  twice to establish communication between your remote terminal and the host, DeskMate.

Note: (ENTER) in the previous paragraph refers to a carriage return. Some terminals use another label for this key, such as (RETURN) or (CR). For the sake of simplicity, however, we use (ENTER) to refer to the carriage return key on both the DeskMate and the remote terminal.

If a DeskMate password exists, PASSWORD: appears on the remote screen (and echoes to the host if not in security mode). Type the DeskMate password, and press <code>ENTER</code>. (For security, the password you type does not echo at either site.) If, in three tries, you do not enter the correct password, Host disconnects the remote site. After the password is correctly entered, the DeskMate Remote Menu appears:

#### DESKMATE REMOTE MENU

- 1) DIRECTORY OF FILES
- 2) RECEIVE FILE FROM HOST
- 3) SEND FILE TO HOST
- 4) READ MAIL
- 5) SEND MAIL
- 6) DISCONNECT FROM HOST

SELECT MENU OPTION >

Type the appropriate menu number, and press (ENTER) to use a remote function. To redisplay the Remote Menu at any time, from any function, press (CTRL) (C). Press (CTRL) (S) to pause during any remote function; press (CTRL) (Q) to resume operation. The remote functions are:

#### DIRECTORY OF FILES

Select Option 1 to display a Directory Menu of the DeskMate file types available:

#### DIRECTORY MENU

- 1) MAIL
- 5) WORKSHEET
- 2) CALENDAR
- 6) AUTOLOG
- 3) TEXT
- 7) ALL
- 4) FILER

SELECT MENU OPTION >

Enter the appropriate number to display a list of all the DeskMate files for a particular application. (AUTOLOG displays the automatic logon files created in TELECOM.) The filenames display across the screen.

Option 7 displays all files in the DeskMate, by application, in the same order in which they are listed on the Directory Menu.

The applications to which the files correspond are identified by the filename extensions: MAIL is /MSG, CALENDAR is /CAL, TEXT is /DOC, FILER is /FIL, WORKSHEET is /WKS, and AUTOLOG is /LOG.

After displaying the files, press **CTRL C** to redisplay the DeskMate Remote Menu.

RECEIVE FILE FROM HOST Select Option 2 to receive a DeskMate file at the remote site. The screen shows:

RECEIVE FROM WHICH HOST FILE?

Enter the filename exactly as it appears in the DeskMate Directory, including the proper filename extension. (If you do not enter an extension, /DOC is assumed.) The contents of the file display on the remote screen. The file displays one line at a time if you are not using automatic line feed at the remote terminal.

Receive File From Host is generally used in conjunction with a printer or RAM buffer option at the remote terminal. Toggle the printer or open the RAM buffer before receiving the file. Consult your terminal's operating instructions for specific information.

(CTRL) (S) pauses receiving/displaying of a file at any time; (CTRL) (Q) continues.

If your terminal software supports it, you may edit a file saved into the RAM buffer and send it back to the DeskMate, using the SEND FILE function. Note that you **must** choose a different name than the original for the edited file.

#### SEND FILE TO HOST

Select Option 3 to send a file from the remote to the DeskMate. The screen shows:

SEND TO WHAT HOST FILE?

Enter a filename for the file you are sending, including the proper filename extension. (If you do not enter an extension, /DOC is assumed.) The filename **must not** match any existing filename in DeskMate.

CTRL S pauses sending/displaying of a file at any time; CTRL Q continues.

#### READ MAIL

Select Option 4 to read a DeskMate message at the remote site. The screen shows:

READ FROM WHICH MAIL FILE?

Enter the name of the MAIL file from which you want to read messages. You do not have to enter the /MSG extension. (For example, enter MESSAGES to read mail from the default file.)

Information for the first message in the file you specified displays. For example, if MESSAGES was specified:

FROM: LAURA

DATE: 02/23/85 10:30am

DESCRIPTION: FANTASTIC NEWS!

(R)EAD OR (N)EXT

Press (R) to read the message, or (N) to display the next message in the specified file. After you display a message, press (N) to go to the next message. NO MORE MESSAGES displays after the last message in the file. Press (CTRL) (C) to return to the DeskMate Remote Menu.

SEND MAIL

Select Option 5 to send a message to the DeskMate from the remote site. The screen shows:

SEND MAIL TO WHICH MAIL FILE?

Enter the name of the MAIL file to which you want to send a message. You do not have to enter the / MSG extension. (For example, enter **MESSAGES** to send mail to the default file.)

The current date and time displays. Then the screen shows:

FROM ? >

Enter your name (up to 8 characters). The screen shows:

DESCRIPTION ? >

Enter a description for the message (up to 32 characters). The screen shows:

ENTER TEXT, TYPE CONTROL C TO END

Type the message, using a carriage return to start a new line as necessary. Backspace is the only editing feature available in message creation. Press (CTRL) C to end the message and send it to the DeskMate. The DeskMate Remote Menu displays.

DISCONNECT FROM HOST

Use Option 6 to disconnect communication between the remote site and the host (DeskMate). The screen shows:

DISCONNECTED BY HOST

Press (BREAK) at the HOST screen in DeskMate after disconnecting communication from the remote site. DeskMate returns to the Main Menu.

## **Passwd**

Press **CLEAR 5** to assign a password for restricting access to DeskMate on initial entry into the system and on exiting the HOST security mode. The screen shows:

Enter New Password:

Type a password of up to 8 characters. A valid password begins with a letter and contains no punctuation or blanks. Press (ENTER). The Main Menu appears.

# Select

Use SELECT to define more than one data file for deletion. Position the marker on the first file you want to select. Press CLEAR 6. Now use the 1 to position the marker on the last file for selection (in the same application column), and DELETE the files.

# Copy

Press **CLEAR 7** to duplicate a selected data file on diskette. The screen shows:

FROM: filename TO:

Enter a filename for the new file.

## **Delete**

Press (CLEAR) (8) to delete all selected files from the DeskMate diskette.

If no files are selected, Enter filename to Delete: *filename* appears. Enter a filename, or press (ENTER) to delete the file currently under the marker.

# Swap

Press **CLEAR 9** to change, or swap, data diskettes. Also use SWAP to designate a drive other than Drive 1 on which to store data files. Enter the number of the diskette drive for the swap. Change diskettes, if applicable, then press any key to continue.

# TEXT OVERVIEW

The TEXT application is an easy-to-use, yet powerful text entry and editing program. Use TEXT to prepare letters, articles, and reports. TEXT replaces your notepad and typewriter, providing an easy way to type your notes and documents, using powerful editing features.

You can search for or search for and replace a word or phrase in your document, rearrange, delete, and insert text, and change the format of your document. You can also print documents, combine documents, and save all or a portion of a document to diskette.

# Help Screens

The two TEXT HELP screens contain brief summaries of the functions and ways to use them. Within the TEXT application, press F2 for the subfunctions. Then, press CLEAR O. After the first HELP screen displays, press ENTER for the second screen. F3 returns to the TEXT screen.

# USING TEXT

To open an existing document file, position the marker over the filename, and press (ENTER). The first entry/edit screen for that document displays. Begin editing the document.

To create a new document file, place the marker over Text and press (ENTER). A blank entry/edit screen for a new document file displays. Begin typing the document. A blank entry/edit screen for a new document file displays. Begin typing the document.

# Typing and Editing a Document

Whether you are creating a new document or editing an existing one, TEXT begins in the ADD (insertion) mode. Everything you type is inserted at the current marker position, and any test following the marker is shifted to the right one space for every character inserted.

The first 22 lines of the TEXT edit screen are for typing and editing your document. (The TEXT functions display on the last two lines.) After you complete the twenty-second line, the screen "scrolls," or moves up line by line, to let you continue. To see a line after it has scrolled off the screen, press until the line appears. Press to return to the last line you were typing or editing.

# Defining and Manipulating Blocks of Text

TEXT allows you to define sections, or blocks, of text in a document so that you can duplicate (COPY), DELETE, and move (INSERT) text within your document.

To define a text block, place the marker on the first character for the block, then press <code>CLEAR</code> <code>(6)</code>. Move the marker to the last character for the block, or press <code>CLEAR</code> <code>(0)</code>, and enter a search string to define everything from the current marker position to that string. All highlighted text is selected. Immediately COPY or DELETE the text. If you choose any other function or exit the document before you manipulate the text, the block is unselected.

To INSERT text elsewhere in your document: First, select a block, then press (CLEAR) (7) to COPY it to the copy buffer. A duplicate of the text block is made. Position the marker wherever you want to INSERT the text, and press (CLEAR) (9). The text block is inserted.

To DELETE text from your document: First, select a block, then press  $\bigcirc$  **(CLEAR)**  $\bigcirc$  The text block is deleted.

To move text from one place to another in your document: First, select a block, then press **CLEAR 7** to COPY it to the copy buffer. Position the marker where you want to INSERT the text, and press **CLEAR 9**. Next, use the deletion instructions above to delete the selected block from its original location.

See "TEXT FUNCTIONS" for more information.

# Arrow Keys

Use the arrow keys to move the marker a character or line at a time. Pressing (SHIFT) or (CLEAR) along with the arrow keys moves the marker more rapidly. Refer to Table 4 for exact marker movement.

Key	by itself	with (SHIFT) moves the marker:	with CLEAR
$\bigcirc$	one character to the right	to the right margin of the current line	Not used
<b></b>	one character to the left	to the left margin of the current line	Not used
	one line up in the current column	to the top of the screen in the current column, or the top of the previous screen if already at the top	0
	one line down in the current column	to the bottom of the screen in the current column, or the bottom of the next screen if already at the bottom	to the end of the document

Table 4. TEXT Marker Movement Keys.

# Printing a Document

You can print a single screen or all of a TEXT document. To print an entire document, use the PRINT function in TEXT. (See "TEXT FUNCTIONS — Print.")

Use the SCREEN subfunction to print everything currently on the screen except the label lines. Use the FIND function or the arrow keys to display the text you want to print.

# TEXT FUNCTIONS

When a document is opened (created or opened for editing), the first page of that document is displayed. The functions available are displayed at the bottom of the screen.

Use these functions to manipulate the text within your document and from document to document. To use a function, hold down the **CLEAR** key, and press the number for the desired function.

## Find

Press **CLEAR (0)** to search for and FIND a string of up to 40 characters. The following prompt appears:

Search string:

If you previously searched for a string, that string also appears. Type the string you want, and press <code>ENTER</code>. If the string is found, the line containing the string displays at the top of the screen. To find the next occurrence of the string, press <code>CLEAR</code> <code>O</code> again, then press <code>ENTER</code> to use the same search string.

**Note:** Uppercase and lowercase differences are ignored in search strings.

### Print

Press **CLEAR 1** to PRINT the entire document. Make sure your printer is ready, and that the printer settings are correct in the PRINTER subfunction (**F2**), then **CLEAR 5**). To stop printing, hold down the **BREAK** key until the printer stops.

# Add/Replace

Press (CLEAR) (2) to toggle TEXT between the ADD and REPLACE modes. ADD (insertion) is the default mode. Everything you type is inserted (added) at the current marker position, and any text following the marker is shifted to the right one space for every character inserted.

In REPLACE (overstrike) mode, each character you type overstrikes (replaces) the character under the marker. The text is not moved. Note that you cannot replace a carriage return. You must skip over a carriage return when in this mode, toggle to ADD mode and insert characters in front ot it, and/or use DELETE to remove it.

## **Format**

You can format the screen to any width you choose. For example, you may want to use the same width as your printed document so that you can see how it will look when printed. The maximum screen width is 79 characters.

Press **CLEAR 3** to specify the screen FORMAT you want to use for your document. The following prompt appears:

Line width = 70

new value:

Enter the number of characters you want to appear across each line on the screen.

# Merge

Press **CLEAR 4** to MERGE (combine) a copy of another document with this document. The following prompt appears:

Enter merge filename:

Enter the name of the document file that you want to MERGE into your document. The length of the document file is checked and, if there is enough room, it is copied into the document at the current marker position.

If there is not enough room in your document for the entire MERGE document file, the merge is canceled, and the screen shows:

Not enough memory

Press (ENTER) to continue.

## Save

Press **CLEAR 5** to SAVE a copy of this document to a diskette file. The following prompt appears:

Enter save filename:

Enter the name of the file to which you wish to SAVE this document. Use standard file name format (*filename.ext:d*). If you do not enter a filename, the document name is used, and the file is saved onto Drive 1 or the drive you specified in the Main Menu SWAP function.

## Select

Use SELECT to define a word or block of text in order to perform some other operation on it. Position the marker on the first character you want to select, and press (CLEAR) (6). Then, use the arrow keys to place the marker over the last character for the block, or press (CLEAR) (0), and enter a search string to select everything from the current marker position to that string. All highlighted text between the first and current marker positions is selected.

After you select your text, COPY or DELETE it, as appropriate. Press (BREAK) if you decide not to use the text you have selected. If you use any other operation or exit the TEXT function before you COPY or DELETE, the text is unselected.

You can use the FIND function to display text for selecting. Use FIND to search for the first character, word, or string you want to include in your text block. Then select the block as usual.

# Copy

Press CLEAR 7 to place all selected text in the copy buffer. COPY does not delete the text, but merely makes a duplicate of it, which you can INSERT somewhere else in your document or COPY to a diskette file. COPY can also save all or part of a document file to diskette or duplicate a diskette file and copy it to this document.

To INSERT copy buffer text at another location: First select a text block, then move the marker to the appropriate position, and press (CLEAR) **9**. The text is inserted at that position.

To COPY text to or from a diskette file, press **CLEAR 7** again. (When copying from a diskette file, do not select text before you use COPY.) The following prompt appears:

From: To:

Enter the name of the diskette file from which you wish to COPY text into this document. The file is inserted at the current marker position.

To copy the text currently in the copy buffer, press (ENTER) to move to the To: prompt. Enter the name of the diskette file to which you wish to copy the text. The text is appended to that file.

If there is not enough room in your document for the entire COPY document file, the copy is canceled, and the screen shows:

Not enough memory

Press (ENTER) to continue.

### **Delete**

Press **CLEAR 8** to DELETE all selected text. The text is immediately deleted. If no text is selected, the character under the marker is deleted.

#### Insert

Press **CLEAR (9)** to INSERT the contents of the copy buffer at the current marker position.

If there is not enough room in your document for the entire INSERT document file, the copy is canceled, and the screen shows:

Not enough memory

Press (ENTER) to continue.

# Exchange

Press  $\bigcirc$  **CLEAR**  $\bigcirc$  to search for a string and replace it with another string. The screen shows:

Search string:

Enter the string you wish to replace. The screen shows:

Replacement string:

Enter the string you wish to exchange for the search string. The first occurrence of the string is found. The screen shows:

Replace? (Y/N)

Press Y to replace this, and each successive occurrence of the string. Press N to skip those that you do not wish to replace with the new string. Press BREAK at any time to cancel any further exchanges.



# WORKSHEET OVERVIEW

WORKSHEET performs mathematical operations on data in rows and columns. This "worksheet" concept lets you easily perform complex calculations for budgeting, forecasting, statistical analysis, engineering, and many other previously tedious tasks.

In addition to the calculations, you can also search for data (FIND), enter TEXT, use a specific data FORMAT, change column width (FORMAT), copy the current worksheet file to diskette or memory, or copy a file from diskette or memory to the current worksheet (MERGE, COPY), and DELETE or INSERT rows, columns, and worksheet data. You may also print all or part of a worksheet.

## Help Screens

The five WORKSHEET HELP screens contain brief summaries of the functions and ways to use them. Within the WORKSHEET application, press **F2** for the subfunctions. Then, press **CLEAR (1)**. After the first HELP screen displays, press **(ENTER)** for the second screen. **(F3)** returns to the worksheet.

The third HELP screen is for the FIND function. Press CLEAR

of for FIND, then F2 for the subfunctions. Next, press CLEAR

for FIND HELP. F3 returns to the worksheet.

The fourth HELP screen is for the FORMULA function. Press (CLEAR) (2) for FORMULA, then (F2) for the subfunctions. Next, press (CLEAR) (0) for FORMULA HELP. (F3) returns to the worksheet.

The last HELP screen is for the FORMAT function. Press CLEAR

4 for FORMAT, then F2 for the subfunctions. Next, press CLEAR

6 for FORMAT HELP. F3 returns to the worksheet.

# THE WORKSHEET

To open an existing worksheet file, position the marker over the filename, and press (ENTER). The first worksheet screen for that file displays.

To create a new worksheet file, place the marker over Worksheet, and press (ENTER). An empty worksheet screen displays for a new file.

WORKSHEET 1	[TABLE	2	3		4	5	ø	2/25/84 6	1Ø:3Øam
2 3 4 5									
6 7 8									
9 1Ø 11									
12 13 14 15									
16 17									
Select Con R lCl	mand:							Free Me	mory 5445
[Ø] [] FIND C		[2] ORMULA	[3] TEXT	[4] FORMAT	[5] MERGE	[6] SELECT	[7] COPY	[8] DELET	[9]

Row numbers appear down the left side of the screen, in the Row Label area. Column numbers appear across the top of the screen (Column Label area). The default width for all columns is ten characters.

Seventeen rows and seven columns (more or less, according to the width you set) display on the screen at one time. This is the "window" concept; a portion of the worksheet is extracted for viewing or editing. There are up to 99 rows and columns available in each worksheet. Use the arrow keys or the FIND function to move from window to window in the worksheet.

Each intersection of a row and a column is a "cell." You enter, calculate, and manipulate text, formulas, and numbers, using cells. The solid rectangular box (highlighted area) is the entry marker. Use the entry marker to mark a cell in which you wish to enter data.

The data entry line, command line, and cell status line appear near the bottom of the screen.

#
Select Command:
R 1C 1 xxxxxx

Free Memory xxxx

The marker marks the data entry line. Add data to the worksheet by positioning the entry marker on the correct cell and entering the data on this line.

Next is the command line, which either prompts you to select a command (function) or to perform some action for the function you are currently using. Error messages and warnings also display on this line.

The next line, cell status, shows the cell currently highlighted by the entry marker (R 1C 1). The formula or cell text contained in that cell displays to the right of the cell number. Number displays if it is a numeric cell. The amount of Free Memory displays at the end of this line.

The WORKSHEET functions display on the last two lines.

# Arrow Keys

Use the arrow keys to move the entry marker from cell to cell and to the Row and Column Labels. The arrow keys move the marker a cell at a time, in the direction of the arrow. Press (SHIFT) or (CLEAR) along with an arrow key to move the marker more rapidly. See Table 5.

Key	· ·	with SHIFT noves the marker:	with CLEAR
-	one cell (or Column Label) to the right	to the last column on the screen, or to the last column on the next screen if the entry marker is in the last column	to Column 99 in the current row
<b>-</b>	one cell (or Column Label) to the left	to the first column on the screen, or to the first column on the previous screen if the entry marker is in the first column	to Column 1, or to the Row Label if entry marker is in Column 1
	one cell (or Row Label) up	to the first row on the screen, or to the first row on the entry marker is in the first row	to Row 1, or to the Column Label if the marker is in Row 1
	one cell (or Row Label) down	to the last row on the screen, or to the last row on the next screen if the entry marker is in the last row	to Row 99 in the current column

Table 5. WORKSHEET Marker Movement Keys.

## Setting Up a Worksheet

When you create a WORKSHEET file, a blank worksheet is shown. Determine the information you want to display and calculate, noting the format and length of your headings and numeric data. The column width defaults to ten characters (9999999.99).

No setup procedures are necessary if you use the default column width. You may begin entering your worksheet data right away. You may, however, tailor the worksheet more specifically to your needs, using FORMAT.

To change the column width, press CLEAR 1 while the entry marker is in Row 1. The marker moves up into the Column Label area. Move the marker onto a column you want to change. To change all columns to the same width, move the entry marker to the column Label area, and press CLEAR 4 for FORMAT. The following message appears on the command line:

Change column width. Specify {ALL, Width}, {Col. no., Width}), {Width}

Type **ALL**, and the new width to change the width of all columns, 1-99 (for example, **ALL**,12 (ENTER)). Type a column number, a comma, and the new width to change the width of a specific column (for example, **C5**,12 (ENTER)). Type only the new width to change the width of the current column (for example, 12 (ENTER)).

# Adding Data to a Worksheet

After you set up the column widths, you are ready to add data to your worksheet. There are four types of data you can enter: numeric data, formulas, cell text, and block TEXT.

To add numeric data to a cell, position the entry marker on the cell, and type the data. (The program uses the default of seven digits, a decimal, and two decimal places, but you can change the data to almost any numeric format.) As you type, the data appears both in the cell and on the data entry line. Press (ENTER) or an arrow key after you complete the cell.

You may add a formula to a single cell or all selected cells. To enter a formula into a cell, position the entry marker on that cell. Press CLEAR 2 to mark the cell for FORMULA entry, then enter the formula on the data entry line. After you enter the formula, it appears on the cell status line.

To enter a formula into several cells, select the cells, using **CLEAR 6**. Next, mark them for FORMULA entry, then enter the formula.

Add cell text (row and column headings, and so forth) as you would numeric data. If you want to use a heading consisting entirely of numbers, type one or more spaces in the cell to mark it as non-numeric.

You may also select a block of cells in which to enter text. When you do this, the text is not bound by each individual cell but by the selected block as a whole. Press (CLEAR) (3) to mark the selected area as a TEXT block, and enter text into it. Press (BREAK) to leave the TEXT mode.

See "WORKSHEET FUNCTIONS" for more information on FORMAT, SELECT, FORMULA, and TEXT.

# Performing Calculations

WORKSHEET calculates data according to cell contents, from left to right and top to bottom. You calculate two or more cells in a row or column. For example, consider the following worksheet:

<b>1</b>	][	2	][	3	][	4	][	5	]
1 DESCRIPTION		Ju	ly	Augu	ust	Sept	em	Avera	age
2		Exper	nd	Expe	end	$Exp\epsilon$	end	Expe	end
3 Total Expend		500.0	00	300.	.00	250	.00		
4 Less:Pers Exp		100.0	00	Ø.	.00	50	.00		
5									
6 Total Expend									

Cells 3,5 and 4,5 use AVG to find the average (mean) values of Rows 3 and 4. The formula is AVG (C2) for each of these two cells. (Average all numeric cells in the current row from the specified to the current column.) Any non-numeric data is skipped.

Cells 6,2, 6,3, 6,4, and 6,5 use an arithmetic operator (-) to find the difference of Rows 3 and 4. Because each of these four cells uses the same formula, R3-R4, first select the cells, then enter the formula on the data entry line.

Note that you can also select the cells, then enter **R3C2-R4C2** as the formula. When WORKSHEET enters a formula into selected cells, it adjusts for the appropriate row or column. (The formula would appear as R3C3-R4C3 in Cell 6,3, R3C4-R4C4 in Cell 6,4, and so forth.)

After you complete the entries to calculate and the formulas to use in calculations, simply press **CLEAR** (1) to CALCULATE the entire worksheet. A result displays in every cell in which you entered a formula.

If a calculated result is a smaller or larger number than WORKSHEET can display or if you attempt to divide a number by zero, an error message displays. \*UNRFLO\* displays for an underflow error; \*OVRFLO\*, for an overflow error; and \*DIVBYO\*, for a division by zero error.

# WORKSHEET FUNCTIONS

The WORKSHEET functions display at the bottom of the screen. To use a function, hold down the **CLEAR** key, and press the number for the desired function.

## Find

Press  $\bigcirc$  to search for and FIND a specific text string or a specific cell. The following prompt appears:

Specify string or RxxCyy:

Enter the cell text you want to FIND. The text must match the cell text **exactly.** If the string is found in one of the worksheet cells, the window containing that cell displays. The entry marker appears on the cell.

When searching for a specific cell, only a valid cell number is allowed. Type R or C, the row or column number, a comma, then C or R, and the column or row number. The window containing that cell displays. The entry marker appears on the cell.

Note that you cannot search for a string entered using the TEXT function. FIND searches for data by cell and therefore disregards TEXT, since it is not cell oriented. Note also that you cannot search for a formula.

## Calc

Press **CLEAR** 1 to CALCULATE the worksheet you set up. Also use this to recalculate a worksheet in which you make changes. Results of the calculation display in the cells in which formulas were entered.

If a cell contains a reference to another cell that is not yet calculated (to a cell to the right and /or below it), it creates a reference error.

Cells which contain a reference error are left blank. After the referred-to cell is calculated you may obtain the correct calculation by pressing <code>CLEAR</code> (1) a second time.

After you save a calculated worksheet, there is no need to recalculate it when you re-enter that worksheet.

### **Formula**

To enter a formula into a cell, position the entry marker on that cell. Press **CLEAR 2** to mark the cell for FORMULA entry, then enter the formula on the data entry line.

To enter a formula into several cells, select the cells, using **CLEAR 6** and the arrow keys. Next, mark them for formula entry, then enter the formula.

Within a formula, mathematical operations are performed from left to right. Parenthetical operations are performed first, multiplication and division second, and addition and subtraction last. When parentheses are nested, the innermost operations are performed first. The operations available for use in formulas are given in Table 6.

	Entering	g Formu	ılas					
between two cells:								
+	Addition	*	Multiplication					
	Subtraction	/	Division					
		!	Power					
	for a row, colum	n, or sel	ected block:					
AVG	Average (mean) of the	MIN	Minimum value					
	values	RMT	Cumulative sum of the					
CMT	Cumulative sum of the		row					
	column	SUM	Sum of the values					
MAX	Maximum value							
	for	a cell:						
ABS	Absolute Value	LOG	Logarithm					
ATN	Arctangent	SGN	Sign					
COS	Cosine	SIN	Sine					
EXP	Exponential	SQR	Square root					
INT	Integer truncation	TAN	Tangent					

Table 6. Formula Operations.

Two special characters are also available. A question mark (?) in a cell indicates a constant that is entered at the time of calculation (CALC). A number sign (#) in a formula indicates that the cell number is not adjusted for each successive row or column, but remains constant. The # is required in CMT and RMT formulas, but is useful in other formulas as well.

Following are examples of formulas using some of these operations.

**?CONSTANT1** Sets up the current cell for entry of a constant (in this example, named CONSTANT1) at the time of calculation

(R1+R2)/R3C4 Adds Cells 1 and 2 in the current column, then divides their sum by the value of Cell R3C4

(C3) – (R1C4) Subtracts the value of the cell in Row 1, Column 4 from the value of the cell Column 3 of the current row

C1\*C2 Multiplies two cells in the same row

 $(\mathbf{R1C2/100})$  Divides the value of the cell in Row 1, Column 2 by 100

C6R3!3 Calculates the cube of the value of the cell in Row 3, Column 6

ABS(R2C3) Multiplies the value of the cell in Row 2, Column 3 by -1 if (and only if) it is a negative number (absolute value)

ATN(R3C5) Displays the arctangent of the value of Cell R3C5
— the angle that has its tangent equal to the value of Cell R3C5 (the result displays in radians; use ATN(R3C5)\*57.29578 to display the arctangent in degrees)

AVG(C1) Adds all the values in the current row, beginning with Column 1, up to the current cell, skipping any non-numeric data, and divides by the number of numeric cells added

CMT(#R4C3) Gives a cumulative total in the current cell or each selected cell for Column 3, beginning with Row 4. For example:

If Cells 4, 5, and 6 of Column 4 are selected and the above formula is entered, calculation produces the following results:

			3	]	4	]
	4	]	5.0	00	5.	ØØ
	5	]	10.0	00	15.	ØØ
E	6	]	20.0	00	35.	00

If you enter the formula only in Cell 6 of Column 4, the result is:

		3	]	Γ	4	]
4	]	5.	00			
5	]	10.	ØØ			
6	]	20.	ØØ		35.1	ØØ

COS(R3C5) Displays the cosine of the value of Cell R3C5 (use COS((R3C5)\* .01745329) if the value in Cell R3C5 is in degrees instead of radians)

**EXP(R4C3)** Displays e raised to the power of the value of Cell 4,3 (Napierian, or natural exponential  $e^x$ )

INT(R4C2) Displays the truncated value of Cell R4C2

LOG(R2C4) Displays the logarithm to the base 10 of the value of Cell R2C4

MAX(C4) Displays the maximum value of the current row, from Column 4 to the current cell, skipping any non-numeric data

MIN(R1) Displays the minimum value in the current column, from Row 1 to the current cell, skipping any non-numeric data

RMT(#R4C3) Gives a cumulative total in the current cell or each selected cell for Row 4, beginning with Column 3. For example:

If Cells 3, 4, and 5 of Row 5 are selected, and the above formula is entered, calculation produces the following results:

If you enter the formula only in Cell 5 of Row 5, the result is:

**SGN(R3C4)** Displays the sign of the value in Cell R3C4 (0 if the argument is zero, 1.00 if the sign is positive, and -1.00 if the sign is negative)

SIN(R2C1) Displays the sine of the value of Cell R2C3 (use SIN((R2C1)\*.01745329) if the value in Cell R2C3 is in degrees instead of radians)

SQR(R5C1) Displays the square root of the value of Cell R5C1

SUM(R5) Displays the sum of all the values in the current column, from Row 5 to the current cell, skipping any non-numeric data

 $\begin{array}{ll} \textbf{TAN(R2C3)} & \textbf{Displays the tangent of the value of Cell R2C3 (use} \\ & \textbf{TAN((R2C3*.01745329) if the value of Cell R2C3} \\ & \textbf{is in degrees instead of radians)} \end{array}$ 

### Text

If you require more space for text than a single cell, or if you want a more formal-looking worksheet, you may select a block of cells in which to enter TEXT. The TEXT boundaries are defined by the selected block as a whole, rather than each individual cell in the block. The program creates a window for writing, editing, and manipulating TEXT.

Press CLEAR 3 to enter (or edit existing) TEXT in a selected area. Word wrapping is automatic, and you may use limited editing features in TEXT. F1 deletes the TEXT character under the marker. CLEAR W deletes text from the entry marker to the end of the word. (Note that you must use an uppercase W.) CLEAR P deletes text from the entry marker to the end of the paragraph (the paragraph end is denoted by #). CLEAR 1 deletes text from the entry marker to the end of the TEXT block.

You may also enlarge a TEXT block. Select a block that completely encloses the present TEXT block. Press (CLEAR) (3). The TEXT block enlarges. (Note that you cannot combine two existing TEXT blocks.) Partial TEXT may be selected, then copied or merged, but the TEXT is copied as individual cells. Press (BREAK) to exit TEXT.

## **Format**

Use FORMAT to change column widths. Press CLEAR while the entry marker is in Row 1. The marker moves up into the Column Label area. Move the marker onto a column you want to change. To change all columns to the same width, move the entry marker to the Column Label area, and press CLEAR 4 for FORMAT. The following message appears on the command line:

Change column width. Specify {ALL, Width}, {Col. no., Width}, {Width}

Type **ALL**, and the new width to change the width of columns 1 - 99 (for example, **ALL**,12). Type a column number, a comma, and the new width to change the width of a specific column (for example, **C5**,12). Type only the new width to change the width of the current column (for example, 12).

Also use FORMAT to specify a certain number format for existing cell data. Place the entry marker on the cell you want to change, and press (CLEAR) (4). The screen shows:

Specify format- L R D I \$:

At the data entry line, enter the letter for the format you wish to use, as follows:

L = left-justified

**R** = right-justified

**D** = decimal (enter number of decimal places, up to 14)

I = integer (whole number)

\$ = dollar format (two digits after the decimal)

(Note that you may enter more than 14 digits after a decimal, but precision is lost after 14.) You may also select a group of cells for which to specify a format.

# Merge

Press **CLEAR 5** to save a selected block to diskette, or insert data from a diskette file at the current marker position, if nothing is selected. One of the following prompts displays:

Enter Save filename:

or

Enter Load filename:

At the data entry prompt, enter the name of the file in which you wish to SAVE the selected block, or from which you wish to LOAD and insert at the current marker position. (If TEXT is encountered while saving, and the entire TEXT block is not included in the selected area, the TEXT is copied as individual cells.)

### Select

SELECT defines a block of the worksheet on which to perform some other operation. Position the entry marker on the first cell for the block, and press (CLEAR) (6). Move the marker to the last cell you wish to include. All selected cells are highlighted.

After you select the block, use FORMULA, TEXT, FORMAT, MERGE, COPY, DELETE, or PRINT on the block. If you use any other function or exit the worksheet, the block is unselected.

# Copy

Press **CLEAR 7** to place a selected area in the copy buffer. If TEXT is encountered and the entire TEXT block is not included, the TEXT is copied as individual cells. Use INSERT to place the contents of the copy buffer in another area on the worksheet.

If no cells are selected, press **CLEAR** (7) to place the current contents of the copy buffer into a document (TEXT file). The screen shows:

Enter filename:

Enter the name of the document file.

### **Delete**

In a Row or Column Label, press **CLEAR 8** to DELETE the entire row or column. All formulas and TEXT blocks are adjusted to correctly reflect the row or column deletion.

On the worksheet, press **CLEAR 8** to DELETE the data in the current cell or all selected cells. If TEXT is encountered and the entire TEXT block is not included in the selected area, the TEXT is skipped, and deletion continues with the next non-TEXT cell.

### Insert

In a Row or Column Label, press **CLEAR 9** to INSERT a blank row or column at the current row or column position. All formulas and TEXT blocks are adjusted to correctly reflect the row or column addition. Note that if you add a new row or column above or to the left of a TEXT block, data in any row or column pushed "under" the TEXT block is lost.

On the worksheet, press  $\overline{\text{CLEAR}}$   $\overline{\textbf{9}}$  to INSERT the contents of the copy buffer at the current entry marker position.

## Print

Press **CLEAR P** to PRINT the selected area of the worksheet or the current window if no area is selected. An area selected for printing may include the entire worksheet. Make sure your printer is set correctly (in Subfunction 5, PRINTER) before you use the PRINT function.

### **Outcomes**

Press **CLEAR (0)** to clear OUTCOMES on the worksheet. Any formulas or other data remain intact; only calculated results are cleared.

# FILER OVERVIEW

The FILER application provides information storage and retrieval. FILER is similar in function to a card indexing system and is easy to set up, maintain, and access. You can refer to the files you set up at any time.

FILER allows you to set up your own data entry form for each file so that you can include any information in any format. You can sort or search for a record by any of the fields you set up on the FILER form. You can also automatically dial a phone number listed in your file, print records or list them to the screen, combine two FILER files, add or delete records from the file, and copy records to another disk file.

# Help Screens

The five FILER HELP screens contain brief summaries of the functions and ways to use them. Within the FILER application, press (F2) for the subfunctions. Then, press (CLEAR) (10). After the first HELP screen displays, press (ENTER) for the second screen. (F3) returns to the main FILER screen.

The third HELP screen is for the FIND function. Press **CLEAR**of for FIND, then **F2** for the subfunctions. Next press **CLEAR**for FIND HELP. **F3** returns to the FILER FIND screen.

The fourth HELP screen is for the DISPLAY function. Press CLEAR

2 for DISPLAY, then F2 for the subfunctions. Next, press CLEAR

5 for DISPLAY HELP. F3 returns to the FILER DISPLAY screen.

The last screen is for the FORM function. Press **CLEAR 4** for FORM, then **F2** for the subfunctions. Next, press **CLEAR 0** for FORM HELP. **F3** returns to the FILER FORM screen.

# USING FILER

To open an existing file, position the marker over the filename, and press **ENTER**. The first record in that file displays.

To create a new file, place the marker over Filer and press (ENTER). A blank FORM screen appears.

Set up a form for a new file, following the instructions outlined in "Setting Up a Form" and "FILER FUNCTIONS — Form."

When you open an existing file, one for which a form is defined, the first record (according to the ORDER you set) displays. A blank FILER entry screen displays if a file form exists, but no records are currently in the file.

Examine or change the displayed record, or press **CLEAR** — to display the next record. If no records are in the file (a blank record form displays), you may enter the data for your first record. (See "Adding Records."

# Setting up a Form

Before you enter records into a file, you must set up a FORM for that file. (If no form exists for a file, the FILER — FORM screen displays after you open the file.) Set up the labels and fields you want to include in your file. (See "FILER FUNCTIONS — Form" for more information.)

If you plan to MERGE this file with another, the forms for the two files must be identical. You may want to make a copy of the current file before you add any records, to assure that the two forms are identical. (See "Merge — Copying a form to use in another file.")

## Adding Records

After you set up a form, a blank form displays for record entry. (If you are opening an existing file, the first record in the file displays. Edit the record, or press **CLEAR** (9) to display a blank form.)

The entry screens are always in the overstrike mode; each character replaces the character at the current marker position. Type the appropriate data for each field. Alphanumeric (letters and numbers) fields are left-justified. Numeric fields are aligned around the decimal or right-justified if there is no decimal. Press (ENTER) after each field. Use the arrow keys to move through the data fields as desired.

Press (CLEAR) (9) to add the record and display another blank form. (F3) adds the record and returns to the main FILER screen.

As you add records, they automatically sort by the primary key field, as determined by the form. If you used the ORDER function, records sort by the key fields first, then the rest of the fields in descending order if necessary. Records sort correctly, regardless of the order in which they are added.

# Arrow Keys

Use the arrow keys to move the marker a character or line at a time Pressing (SHIFT) or (CLEAR) along with the arrow keys moves the marker more rapidly. See Table 7.

Key	by itself	with (SHIFT) moves the marker:	to the next FIND match or to the next record		
$\overline{}$	one character to the right	to the field area in FORM			
	one character to the left	to the Label area in FORM	to the previous FIND match or to the previous record		
	one line up in the current column or to the first character in the previous field	to the first field on the screen	to the first FIND match or to the first record on file		
	one line down in the current column or to the first character in the next field	to the last field on the screen	to the last FIND match or to the last record on file		

Table 7. FILER Marker Movement Keys.

# Printing Records

You can print all or part of a FILER file. To print one, several, or all records, use the PRINT function. (See "FILER FUNCTIONS — Print.") The records print horizontally across the paper.

You can also use the SCREEN subfunction to print a single record. Screen prints the record in the same format as it appears on the screen. Use the FIND function or the arrow keys to display the record you want to print.

# FILER FUNCTIONS

The FILER functions display at the bottom of the screen. To use a function, hold down the **CLEAR** key, and press the number for the desired function.

### Find

Press **CLEAR 0** to search for and FIND a record or group of records. The FIND function screen displays a blank form with the FIND functions (EQUAL, GREATER, LESS, RESET, MARK) at the bottom of the screen. The marker is on the primary key (ORDER) field

Press (CLEAR) and a function number (1), (2), or (3) to set the FIND criteria EQUAL to, GREATER than or equal to, or LESS than or equal to the information you have typed in that field. The default is EQUAL. (Choose the function any time the marker is over the appropriate field — before, during, or after you enter the data.)

Press (F3) to begin the search. If search criteria exists for more than one field, FIND searches for records that match all the criteria. All records that match the criteria are found, and the first one displays. Use (CLEAR) with the (-) and (-) keys to scroll forward or backward through the records.

Special FIND functions are:

RESET

Press **CLEAR 4** to RESET the FIND criteria. The records are reset, and the main FILER screen is displayed.

MARK

Press (CLEAR) (6) to MARK (or unmark) fields to appear when the DISPLAY and PRINT functions are used. Marked fields are visible — displayable or printable. An asterisk appears in the Label area of all visible fields. Invisible fields do not DISPLAY or PRINT. The default is visible.

### Call

Press CLEAR ① to dial any phone number currently highlighted. If you are using an auto dialing modem and a valid sequence of numbers is highlighted, the number is dialed. Pick up the telephone receiver for normal conversation. FILER operation resumes at the point at which you made the request. Check the Voice Dialing settings in TELECOM before you use CALL.

# Display

Press **CLEAR 2** to displays a list of all records that match the FIND criteria.

A label line displays at the top of the screen. The data for the records chosen displays horizontally; the data for each field appears under its corresponding label. The length of each field is determined by the maximum length of data for that field. Two spaces are inserted between each field.

**Wrapping.** If the records take up more than 80 characters across the screen, the records (label line and data lines) wrap to the next line, indented five spaces.

Eliminating fields from the display. If you do not wish to display certain fields, unmark those fields in FIND.

Scrolling through the records. If more records are chosen to display than will fit on the screen, use the arrow keys to scroll through the records. (See "Arrow Keys.")

Press (F3) to return to the main FILER screen.

### **Print**

Press **CLEAR 3** to PRINT a list of all records that match the FIND criteria. Make sure that you have first set the printer settings in Subfunction 5, PRINTER.

The record list prints. A label line appears across the top of the paper. The data for the records chosen prints horizontally; each field appears under its corresponding label. The length of each field is determined by the length you set up in the FORM function. Two spaces are inserted between each field.

**Wrapping.** If the records use more characters than are available on one line, the records (label line and data lines) wrap to the next line, indented five spaces.

Eliminating fields from the list. If you do not wish to print certain fields, unmark those fields in FIND.

### Form

Press **CLEAR 4** to display the FORM screen. For each field you want to include in your record, you must set up a field in FORM. A form field line consists of a Label and a Field area. You can define a form with up to 21 fields. Press **F3** to save the form.

#### Defining a Label

The left side of the screen is reserved for field labels. A label always begins at the left margin. Type one or more characters (up to 15) on a line in this area to create a new field on that line. Press (ENTER) after you complete the label. The Label area fills in with a line of dots and a colon. The marker is positioned to set up the FORM for the Field area.

Note: For blank lines between field lines, press **ENTER** or **I** before you enter any characters in the Label area.

#### Defining a Field Area

Press **ENTER** in the first position of the Field area to display a line of dots, and specify a maximum of 58 alphanumeric characters for the data in this field. (See "NUMBER" if you want to set up a numeric field.) Press **ENTER** again to move to the next line.

You may also type up to 255 dots and press (ENTER) for a maximum length equal to the number of dots you type. If the field length is greater than 58, it wraps to the Field area in the next line. The Label area on that line is left blank.

You can also use "edit" characters — characters that convey a certain type of required entry — in either alphanumeric or numeric data fields. A common use of edit characters is for formatting telephone numbers; for example:

(...) ...-...

The parentheses and the dash are edit characters; they are skipped over during data entry. Use a comma (,) as an edit character in a numeric field to indicate the placement of a decimal point.

#### Form Functions

Special FORM functions are:

ORDER

In data entry, records are sorted in the ORDER you set here. The ordered, or key, fields are sorted first, in ascending order. Then, the rest of the fields are sorted in their order of appearance on the screen. The priority number of ordered keys appears in the Label area on the screen.

Press **CLEAR 0** to make the field under the marker a key field. The screen shows:

Priority number:

Enter the next available priority for this key (in 1, 2, 3 order). If you press **ENTER** without entering a priority number, the field is given the next available number (1 if no fields are ordered yet). The priority number appears in the Label area.

If you choose a field that is already a key, press (ENTER) to leave the priority unchanged, or enter a new priority. If an existing priority is used, the priority numbers are shifted to allow for it.

A priority number of  $\emptyset$  removes the key status of a field and reorders the keys.

PACK

Press CLEAR 1 to PACK the file when the efficiency decreases because of many additions, deletions, and changes to records. The file efficiency (A, B, C, or D) displays on the FORM screen. PACK if the efficiency drops below B. If efficiency drops to D, it displays on the main FILER screen. Use PACK to recover lost diskette space.

NUMBER

Press **CLEAR 2** to specifly the field under the marker as numeric field. A number sign (#) appears in place of the colon for a numeric field. (Press **CLEAR 2** again to change the field back to alphanumeric.)

USE THE FORM FUNCTION REGULARLY TO CHECK THE EFFICIENCY LEVEL.

If the field is not yet set up, press (CLEAR) (2), then (ENTER) to set up the field as: 12 digits, a decimal, and 2 decimal places. (A comma represents a decimal in FORM.) You may edit the number of digits on either side of the decimal with ADD or DELETE. Data entered in the field aligns around the decimal.

If the field is already defined, NUMBER simply right-justifies any data entered in the field when you display or print it.

DELETE

In the Field area, press **CLEAR 8** to DELETE the character under the marker.

In the Label area, press **CLEAR 8** to DELETE the entire field, including the label.

ADD

In the Field area, press **CLEAR 9** to ADD one character at the current marker position.

In the Label area, press **CLEAR 9** to ADD a new field at the current marker position. All fields below the marker move down one line.

# Merge

Press **CLEAR 5** to MERGE another FILER file into the current file. The screen shows:

Merge from:

Enter the name of the file you want to merge into this file. If the file forms are **exactly** the same, copies of all the records in the (from) file are merged into this file. If duplicate records exist in the two files, the extra records are not merged into the file.



# Add

Press **CLEAR 9** to ADD a record to the file. A blank record form appears. Type the record data. Press **ENTER** after completing each field.

When a record that you are adding or editing is displayed, press (CLEAR) (9) to update the record on the screen. A blank record form for adding another record displays. If you do not wish to add another record, press (F3) to update the record on the screen and return to the main FILER screen.

Copying a form to use in another file. When you merge two files, the forms of the files must be identical. Since one character difference makes the files incompatible, make a copy of this file after you set up your form (before you enter any records). You can do this at the operating system level or at the Main Menu.

At TRSDOS Ready, type **COPY** oldfile /FIL:1 TO newfile /FIL:1 **ENTER**) to make a duplicate of the file. The first name is the file from which you are copying; the second is the destination file.

### Select

SELECT the contents of a record for copying to a document file on diskette. Place the marker over the first field's data to select, then press CLEAR 6. Move the marker to the last field to include. All selected data is highlighted. Now COPY the selected area.

# Copy

Press **CLEAR (7)** to COPY to a document file on diskette the field contents of a selected record. The screen shows:

T0:

Enter the name of the diskette file into which you wish to COPY the data. The data appends to the specified document file.

### **Delete**

Press (CLEAR) (8) to DELETE the record currently displayed.

# TELECOM OVERVIEW

TELECOM is a telecommunications application, designed for communication between the DeskMate computer and another computer running a host program. TELECOM can transmit and receive any type code, including machine-language. Hookup to the host computer may be over telephone lines or direct.

## Help Screens

There are several TELECOM HELP screens. These screens contain brief summaries of the functions and ways to use them. Within the TELECOM application, press **E2** for the subfunctions. Then, press **CLEAR 1** to display general TELECOM HELP. HELP is also available for Modem Definition, Computer Dialing Definition, Voice Dialing Definition, Answer Mode Definition, and TERMINAL.

Choose a function, then press **F2**, then **CLEAR 0** to display HELP for that function. Press **ENTER** for each successive screen. **F3** returns to the appropriate TELECOM screen.

# Setting the Status

The first step in communicating with a host computer is to connect a modem to the DeskMate computer. Refer to your modem's operating instructions for details.

After the modem is properly connected and set, place the marker over Telecom, and press (ENTER). The screen shows the Current (default) Telecom Status Settings:

releco	n								Ø2/2	5/85	10:39	ðam
Current	t Status	Settings	:									
BAUD I	Rate	iodem			110	No 15%	300	600	12ØØ	24ØØ	48ØØ	96Ø
Parity	y				Even	Odd	None					
		OFF				2 No						
ASCII	Characte	er Filter			Yes	No						
		l				No No						
						NO						
[Ø]	[1]	[2]	[3]	[4]	BUFFI [5]			Used:	,		ee: x	
	6 3	1 403	1 7 3	1 7 1	101		[6]	[7]		8]	[9]	100

To change a setting, use the arrow keys to move the marker to the correct value, then press **ENTER**. The new setting is highlighted. (Hold down **SHIFT**), and press **1**, **1**, **-** or **-** to move to the top line, bottom line, leftmost value, or rightmost value.)

If you are using an Auto Dialing Modem, change the status to Yes. Note that if you are directly connecting the DeskMate as host to another computer, the Auto Dialing Modem status **must** be No.

Refer to the host's requirement for BAUD Rate, Word Length, Parity, and number of Stop Bits settings. In most cases, you can use the default values. Check your modem's operating instructions for its maximum baud rate. (The 4800 and 9600 baud rates are for transmission between computers that are directly connected.)

If you use Support XON/OFF, transmission to a host computer stops when the host sends an XOFF. Transmission resumes when the host sends an XON. Also, TELECOM sends an XOFF to pause transmission from the host computer when data is coming in too fast for the input buffer to handle it. TELECOM sends an XON to resume transmission.

Turn on the ASCII Character Filter to display only codes 20-7F Hex, 08, 09, 0A, 0C, 0D, and 1B. The ASCII filter strips out all characters over 80 Hex and control characters except backspace, horizontal tab, line feed, form feed, carriage return, and escape.

Turn on the Auto Line Feed to add a line feed  $(X'\emptyset A')$  after each carriage return  $(X'\emptyset D')$  received. Turn the option off to accept incoming line feeds and carriage returns "as is."

Use the Self Echo option if the host does not echo the text you send (half duplex). If the host echoes the text, turn off the Self Echo (full duplex).

Enter the number of Retries you want if, when you are dialing a phone number or executing an automatic logon sequence, No Carrier is detected.

# **TELECOM FUNCTIONS**

The TELECOM functions display at the bottom of the screen. To use a function, hold down the (CLEAR) key, and press the number for the desired function.

### Reset

Press CLEAR 0 to RESET the TELECOM Status screen to the default settings. Current settings are always highlighted.

## Select

Press CLEAR 1 to change the current status line to the setting under the marker. Alternately, you may place the marker on a setting, and press (ENTER) to select it. At Auto Dialing Modem, selecting Yes displays the Modem Definition screen. Following are the Modem Definition functions for voice dialing, computer dialing, and answer mode

#### COMP

Computer Dialing Definition defines the dialing sequence your modem uses when executing auto logon sequences in TERMINAL. (This is the dialing sequence, not the logon sequence.) Determine the specific dialing sequence for your modem, then press CLEAR 1 to display the Computer Dialing Definition functions.

Press (CLEAR) 1 to send the phone NUMBER to the DeskMate modem. Send Phone Number to Modem appears on the screen.

Press (CLEAR) 2 to RECEIVE text from the modem. Receive: appears on the screen. Type the text you expect to receive from the modem, and press (ENTER).

Press (CLEAR) (3) to SEND text to the modem. Send: appears on the screen. Type the text to send, and press (ENTER).

Press (CLEAR) (4) to PAUSE during a command sequence. Pause: appears on the screen. Type the number of seconds to pause, and press (ENTER).

Press **CLEAR 5** (WAITNC) to Wait for No Carrier detect before continuing. Wait for no Data Carrier Detect appears on the screen.

Press (CLEAR) (6) (WAITC) to Wait for Carrier detect before continuing. Wait for Data Carrier Detect appears on the screen.

Press **CLEAR (8)** to DELETE the line under the marker.

Press **CLEAR 9** to INSERT a blank line at the current marker position.

Press **[3]** to save the completed computer dialing sequence and return to the Status screen.

VOICE

Voice Dialing Definition defines the dialing sequence your modem uses when auto dialing phone numbers in the PHONE and FILER applications. Determine the specific sequence for your modem, then press (CLEAR) (2) to display the Voice Dialing Definition functions. The Voice Dialing functions are the same as those for Computer Dialing.

Press (3) to save the completed voice dialing sequence and return to the Status screen.

#### **ANSWER**

Answer Mode Definition defines the answer sequence your modem uses for answering the remote when DeskMate is in the Host mode. Determine the specific answer sequence for your modem, then press CLEAR 3 to display the Answer Mode Definition functions.

Press **CLEAR 2** to RECEIVE text from the remote modem. Receive: appears on the screen. Type the text you expect to receive from the modem, and press **(ENTER)**.

Press (CLEAR) (3) to SEND text to the remote modem. Send: appears on the screen. Type the text to send, and press (ENTER).

Press (CLEAR) (4) to PAUSE during a command sequence. Pause: appears on the screen. Type the number of seconds to pause, and press (ENTER).

Press CLEAR (5) (WAITNC) to Wait for No Carrier detect before continuing. Wait for no Data Carrier appears on the screen.

Press (CLEAR) (6) (WAITC) to Wait for Carrier detect before continuing. Wait for Data Carrier Detect appears on the screen.

Press **CLEAR 8** to DELETE the line under the marker.

Press **CLEAR 9** to INSERT a blank line at the current marker position.

Press (F3) to save the completed answer sequence and return to the Status screen.

# Autolog

Press **CLEAR 2** to execute an automatic logon sequence. The name of the auto logon file currently in RAM (if any) displays at the bottom of the screen. Press **ENTER** to use the current file, or enter the filename for the auto logon you wish to use.

If the carrier is detected, TELECOM executes the auto logon sequence and goes into the interactive TERMINAL mode. If no carrier is detected, TELECOM waits 5-10 seconds, then redials (if the Retries setting on the Status screen is greater than 0).

# **Editlog**

Press **CLEAR 3** to create or edit an automatic logon sequence. The name of the auto logon file currently in RAM (if any) displays at the bottom of the screen. Press **ENTER** to use the current file, or enter a filename for the auto logon you wish to create or edit.

If you are creating a new file, File not in directory displays. Press (ENTER) again. The Autolog Editor screen appears. Use the functions to create an autolog sequence, entering the appropriate prompts or responses for the host computer. Note that to enter the control character (^) in the logon sequence, you press (CLEAR) (;). Special EDITLOG functions are:

Press **CLEAR (0)** to place the current status in the autolog sequence. The Status screen displays. Set the status as you want it, then press **(F3)**. A summary of the status displays on the screen.

Press **CLEAR** 1 to place a dialing sequence in the autolog sequence. Type the dialing sequence, and press **ENTER**.

RECEIVE Press CLEAR 2 to RECEIVE text (a host prompt) from the host computer. Receive: appears on the screen. Type the text you expect to receive from the host, including any control codes, and press (ENTER).

SEND Press (CLEAR) (3) to SEND text (your response to the host prompt) to the host computer. Send: appears on

the screen. Type the text to send, and press **ENTER**.

PAUSE Press CLEAR 4 to PAUSE during a command

sequence. Pause: appears on the screen. Press (ENTER) for 1 second, or type the number of seconds

to pause, and press **ENTER**.

DELETE Press CLEAR 8 to DELETE the sequence line

under the marker.

INSERT Press (CLEAR) (9) to INSERT a blank sequence line

at the current marker position. Use the appropriate

function to enter the sequence item.

Press (F3). Press (ENTER) to save the completed auto logon sequence in the current file. Enter a new filename to save the sequence in a different file. The Status screen returns.

### **Terminal**

Press (CLEAR) 4 to enter the interactive TERMINAL mode. In the interactive terminal mode, characters you type are sent to the host program. Incoming characters display as they are received. If the host program echoes your transmissions, they display also. (If the host does not echo, you can use the self echo option on the Status screen to display your keyboard input.) Special TERMINAL functions are:

BUFFER

Press CLEAR ① to open or close the RAM BUFFER for capturing the text of the TERMINAL session. You may examine the text later, using the DISPLAY or PRINT function on the Status screen. When you open the buffer, incoming text appends to the current buffer contents. A "BUFFER FULL" message is displayed whenever applicable.

CLEAR

Press **CLEAR** 1 to CLEAR the contents of the RAM buffer. All data in the buffer is lost when you use this function.

RECEIVE

Press (CLEAR) (2) to RECEIVE a downloaded file from the host computer. Receive What File? appears on the screen. Type the filename, and press (ENTER). There are no restrictions on file type.

Note: Use 8-bit transmission, and turn off all filters and character translation options when receiving binary data.

SEND

Press **CLEAR 3** to SEND (upload or transmit) a diskette file to the host computer. Send Which File? appears on the screen. Type the name of the diskette file, and press **ENTER**.

PRINTER

Press (CLEAR) (4) to turn on or off the PRINTER option. When the option is on, the text of the TERMINAL session is sent to the printer as it is received and displayed. (If the ASCII Character Filter is on, only codes 20-7F Hex, 08, 09, 0A, 0C, 0D, and 1B are sent.)

When the PRINTER option is on, transmission is much slower. Also, if the baud rate at which you are transmitting is greater than the maximum character input rate of your printer, some characters are lost as they are sent to the printer. Check your printer's specifications for its maximum character input rate.

BREAK

Press **CLEAR 5** to generate a BREAK sequence (250ms null).

CALL

Press (CLEAR) (6) to auto dial a phone number (for example, an information service number). Call which number: appears on the screen. Type the dialing sequence, and press (ENTER). If a carrier is detected, TELECOM goes to the interactive terminal mode. If no carrier is detected, TELECOM waits 5-10 seconds, then redials (if the number of retries on the Status screen is greater than 0).

DISC

Press **CLEAR 7** to DISCONNECT communication with the host (hang up the phone).

Press [53] to return to the Status screen.

# **Display**

Press CLEAR 5 to DISPLAY the contents of the RAM buffer. Press SHIFT @ to pause the display. Press any key to continue. Press any key to return to the Status screen after the buffer display is complete.

### Print

Press (CLEAR) (6) to PRINT the contents of the RAM buffer. The Status screen displays after the buffer print is complete.

### Save

Press (CLEAR) (7) to SAVE the contents of the RAM buffer on diskette as a document (TEXT application) file. Enter a filename for the document. The Status screen displays after the file is saved.

### Load

Press **CLEAR 8** to LOAD a file from diskette to the RAM buffer. Enter the name of the file from which to load. The Status screen displays after the file is loaded.

# Clear

Press **CLEAR 9** to CLEAR the RAM buffer. All contents are lost when the buffer is cleared.

# CALENDAR OVERVIEW

The CALENDAR application is an event scheduler. It can be used as a general purpose calendar and planner to replace your desk calendar and datebook. It records important events, their dates, and their times so that you can refer to them at any time. It also maps the times that events are scheduled for the entire week, beginning with the current day. You can see your weekly schedule at a glance.

You can search for an event by date, time, and description, print a list of and set the alarm for selected events, combine two CALENDAR files, add and delete events from the calendar, and copy events to another disk file.

# Help Screens

The three CALENDAR HELP screens contain brief summaries of the functions and ways to use them. Within the CALENDAR application, press **F2** for the subfunctions. Then, press **CLEAR (D)**. After the first HELP screen displays, press **ENTER** for the second screen. **(F3)** returns to the main CALENDAR screen.

The third HELP screen is for the FIND function. Press **CLEAR O** for FIND, then press **F2** for the subfunctions. **F3** returns to the CALENDAR FIND screen.

# USING CALENDAR

To open an existing event file, position the marker over the filename, and press (ENTER). A listing of events in that file displays in chronological order.

To create a new file, place the marker over Calendar, and press (ENTER). A CALENDAR entry/edit screen displays.

In the upper left corner of the screen is the Weekly Time Chart. The days of the week (Mon, Tue, and so forth), beginning with the current day, display down the left side of this area. The times of day, beginning with 12:00am, display across the top.

Any events for the week are marked with asterisks (\*) in the day and time slots to which they correspond. When event times conflict with each other, the conflicting times are marked with an exclamation point (!).

In the upper right corner of the screen is the Month Calendar, which is similar to a standard desk calendar. The current date is highlighted.

In the bottom section of the screen is the Daily Events Calendar, in which events are entered and displayed.

# Adding Events

CALENDAR is always in the overstrike mode; each character replaces the character at the current marker position. Add an event on a blank line simply by entering the appropriate data. Enter the fields as follows:

Enter the DATE of the event in mm/dd/yyyy format. For example, type 10/22/1984 (ENTER) for October 22, 1984. Press (ENTER) to use the current date.

Enter the time (12-hour) at which the event BEGINs in 00:00x format. For example, type 0730a (ENTER) for 7:30am.

Enter the time (12-hour) at which the event ENDs in 00:00x format. For example, type 1208p (ENTER) for 8 minutes after noon.

Enter a DESCRIPTION of up to 44 characters for the event. (No uppercase/lowercase distinctions are made when searching for events.  $\bf A$  and  $\bf a$  are the same.)

After an event file is created and contains events, the display/entry screen displays the events for the current day. To add an event, use the ADD function ((CLEAR) (9)). (See "CALENDAR FUNCTIONS.")

Events automatically sort in DATE/TIME order regardless of the order in which they are added to the file.

# Defining and Manipulating Event Blocks

CALENDAR allows you to define sections, or blocks, of events that you can duplicate and save to a TEXT file (COPY), MERGE with a CALENDAR or ALARM file, or DELETE. To define a text block, first SELECT it. Once the text is selected, immediately MERGE, COPY, or DELETE it. If you choose any other function or exit the file, the block is unselected.

Copying events to a TEXT file. To copy events to a TEXT file, select the beginning of the block you want by pressing CLEAR 6. Position the marker on the last event for the block. Press CLEAR 7 to save the file into the copy buffer. Press CLEAR 7 again, and enter the name of the file to which you wish to copy.

**Deleting events.** To delete events, select the beginning of the block you want by pressing (CLEAR) (6). Position the marker on the last event for the block. Press (CLEAR) (8). The text block is deleted.

See "CALENDAR FUNCTIONS" for more information on these functions.

# Arrow Keys

Twelve event lines can be shown on the screen at one time. After you complete the twelfth line, the events "scroll," or move up line by line, to let you continue. To see a line after it has scrolled off the screen, press \( \bullet until the line appears. Press \( \bullet to return to the last line you were typing or editing.

Use the arrow keys to move the marker a character or line at a time. Pressing (SHIFT) or (CLEAR) along with the arrow keys moves the marker more rapidly. See Table 8.

Key	by itself	with SHIFT moves the marker:	with CLEAR
$\overline{}$	one character to the right	to the beginning of thefirst field to the right	to the next day
	one character to the left	to the beginning of the first field to the left	to the previous day
T)	one line up in the current column	to the first event line on the screen	to the first FIND match
	one line down in the current column	to the last event line on the screen	to the last FIND match

Table 8. CALENDAR Marker Movement Keys.

# Printing a List of Events

You can print all or part of a CALENDAR file. To print the entire file or more than one screen of events, use the PRINT function. (See "CALENDAR FUNCTIONS — Print.")

To print only a few events that are displayed on the screen, use the SCREEN subfunction. SCREEN prints everything currently on the screen. Use FIND, DATE, or the arrow keys to display the events you want to print.

# CALENDAR FUNCTIONS

The CALENDAR functions available display at the bottom of the screen. To use a function, hold down the **CLEAR** key, and press the number for the desired function.

### **Find**

Press (CLEAR) (1) to search for and FIND an event. An event line containing the current (default) FIND settings displays. (A line containing the current date and asterisks in each of the fields displays if no search criteria have been entered.) The FIND functions (EQUAL, GREATER, LESS, RESET) display at the bottom of the screen.

To use the default settings, simply press **F3**. All events that match the criteria are found, and the first 12 display. If more than 12 events match the criteria, use the **1** and **1** keys to scroll forward or backward throught the events.

If no criteria are entered or if you want to change the search criteria, enter the data for which you wish to search.

\* and ? are "wildcard" indicators. Enter \* in a field to disregard that field when searching for a match. Type \* before or after data in a field to disregard all characters that come before or after the data, respectively. ? is similar to \* except that it disregards only one character.

Type the search data for each field (including \* and ? if you wish), and press **ENTER**). Press **CLEAR**) and a function number (**1**), **2**), or **3**) to set the FIND criteria equal to, greater than or equal to, or less than or equal to the information you have typed in that field. (Choose the function any time the marker is over the appropriate field, before, during, or after you enter the data.)

Press  $\cite{F3}$  to begin the search. All events that match the criteria are found, and the first 12 display. If more than 12 events match the criteria, use the  $\cite{1}$  and  $\cite{1}$  keys to scroll forward or backward through the events.

Reset FIND Criteria. Press CLEAR 4 to RESET the FIND criteria. All fields are cleared back to their original settings.

### Date

Press **CLEAR** 1 to search for and display events that match a certain DATE. The screen shows:

Enter Date: mm/dd/yyyy

Type a new date, and press (ENTER). (Use a four-digit year.) The current CALENDAR date changes to the date you enter. (The system date is not affected.) All events for the date specified are found, and the first 12 display. If more than 12 events match the date, use the and the keys to scroll forward or backward through the events. The Weekly Time Chart and the Month calendar are updated to reflect the date you enter.

### Print

Press **CLEAR 3** to PRINT a list of all events chosen with the FIND function or that match the current date if FIND is not used. Check the settings in the PRINTER subfunction to be sure your printer is set up properly.

### Alarm

Press **CLEAR 4** to place into the ALARM file all selected events. The alarm for each event is set at 30 minutes prior to the scheduled BEGIN time of the event. If the BEGIN time is zero, no alarm is set for that event. See the ALARM chapter of this manual for more information.

# Merge

Press (CLEAR) (5) to MERGE all selected events into another CALENDAR file or to merge another CALENDAR file with this event file if no events are selected.

Merging another file into the current file. If no events are selected, the screen shows:

Merge from:

Enter the name of the event file to merge into this file. Copies of all events in the from file merge into the current file.

Merging selected events into another file. If any events are selected, the screen shows:

Merge to:

Enter the name of the event file into which you wish to merge the selected events. Copies of all selected events in the current file merge into the to file.

### Select

Use SELECT to define an event or a block of events in order to perform some other operation on it. Position the marker on the first event line you want to select, and press (CLEAR) (6). Use the arrow keys to place the marker over the last event for the block. (See Table 8 for arrow key movement.) All selected events are highlighted as you more the marker.

After you select the events, MERGE, COPY, DELETE, or place them in the ALARM file, as appropriate. If you use any other function or exit the CALENDAR application before you perform one of the above operations, the events are unselected. You can also use FIND to search for the events you want to select.

# Copy

Press **CLEAR 7** to put all selected events into the COPY buffer. Press **CLEAR 7** again to COPY the contents of the copy buffer to a document file on diskette. The screen shows:

Copy to:

Enter the name of the diskette file to which you wish to copy the events. The events append to the document file.

### **Delete**

Press (CLEAR) (8) to DELETE all selected events. The events are immediately deleted. If no events are selected, the event line under the marker is deleted.

#### Add

Press **CLEAR 9** to ADD a new event. A blank event line appears. Type the appropriate data: DATE, BEGIN and END times (including **a** or **p** for a.m. or p.m.), and DESCRIPTION. Press **ENTER** after each field.

When you add an event that conflicts with the time of an existing event, the conflicting times are marked with an exclamation point in the Weekly Time Chart.

Day events. If no times are entered for an event, it is considered a "day" event — for the entire day — and it is not put into the Weekly Time Chart.

### MAIL OVERVIEW

The MAIL application supports a simple message handler. It records important messages along with their dates, times, and authors. You can write or read a message at any time. You can also print a list of or delete messages.

#### Help Screens

The two MAIL HELP screens contain brief summaries of the functions and ways to use them. Within the MAIL application, press F2 for the subfunctions. Then, press CLEAR ①. After the first HELP screen displays, press ENTER for the second screen. F3 returns to the MAIL screen.

# USING MAIL

To open the default MAIL file, MESSAGES, place the marker over Mail and press (ENTER).

To open an existing message file, position the marker over the filename, and press (ENTER). A listing of the messages in that file displays in ascending date/time order.

Each message line in the listing includes: the name of the author of the message, the date and time of the message, and a brief description of the message. Use the arrow keys to scroll through the listing if there are more than 20 messages.

#### Adding Messages

To add a message to a MAIL file, use the CREATE function, CLEAR

1. After you enter the identifying information, the TEXT entry/edit screen appears. Type your message, using any of the TEXT editing features and functions.

The TEXT editor begins in the ADD (insertion) mode. Everything you type is inserted at the current marker position. Any text following the marker shifts to the right one space for every character inserted.

The first 22 lines of the editor screen are for typing and editing your message. After you complete the twenty-second line, the screen "scrolls," or moves up line by line, to let you continue. To see a line after it scrolls off the screen, press \_\_\_\_\_ until the line appears. Press \_\_\_\_\_ to return to the line you were typing or editing.

The TEXT functions display at the bottom of the screen. Use any of the TEXT functions for your message. See "TEXT FUNCTIONS" in the chapter on TEXT for more information.

Press  $\textcircled{\textbf{F3}}$  to save the message and return to the message listing screen for the current file.

#### Arrow Keys

Use the arrow keys to move the marker a character or line at a time. Pressing (SHIFT) or (CLEAR) along with an arrow key moves the marker more rapidly. See Table 9.

Note that on the TEXT editor screen, the arrow keys are used in exactly the same way as they are in the TEXT application.

Key	by itself	with SHIFT moves the marker:	with CLEAR	
$\overline{\Box}$	Not used	Not used	to the next message	
<b>(</b>	Not used	Not used	to the previous message	
	one line up in the current column	to the top of the screen	to the beginning of the file	
<b>I</b>	one line down in the current column	to the bottom of the screen	to the end of the file	

Table 9. MAIL Marker Movement Keys.

#### Printing Messages

You can print all or part of a message in a MAIL file. To print an entire message, place the marker over it on the listing screen, then press (CLEAR) (3) (PRINT).

You may also print a message at the TEXT editor screen, using the TEXT PRINT function. (See "TEXT FUNCTIONS — Print" in the TEXT chapter.)

To print part of a message, use the SCREEN subfunction. SCREEN prints everything currently on the screen.

# MAIL FUNCTIONS

The MAIL functions display at the bottom of the message listing screen. To use a function, hold down the **CLEAR** key, and press the number for the desired function.

#### Find

Press (CLEAR) (1) to search for and FIND a particular message. Enter the author (FROM), DATE, and DESCRIPTION of the message. All messages that match the search criteria display. DISPLAY, PRINT, or DELETE the message, or FIND or CREATE another message. Press (BREAK) to return to the main message listing.

#### Create

Press CLEAR 1 to CREATE a message. The CREATE MAIL screen appears. The DATE of the message you create is automatically determined by the current system date and time. Enter your name or the name of the author of the message (FROM). Next, enter a brief description (40 characters maximum) of the message.

The last prompt is for the person to whom the message is written (T0). The name you enter here is the name of the data file in which you want to store this message. Press (**ENTER**) to skip T0 and default to the current file.

After the message information screen is compete, a TEXT entry screen displays.

Type the message using TEXT functions and editing features. Press **F3** to save the message in the current MAIL file (the T0 name). The message listing screen returns. The data you entered on the CREATE MAIL screen displays in the listing.

#### **Display**

With the marker on the listing of the message you want to DISPLAY, press (CLEAR) (2). The TEXT entry/edit screen for that message displays. Use the arrow keys to scroll through the message.


Press  $\P$  to return to the listing screen. Press  $\P$  at Save new message? (Y/N) if you made changes to the message that you want to save. The changes are saved as a new message, with the current date and time. The original message remains unchanged. Pressing  $\P$  at Save new message? (Y/N) simply exits the message without saving any changes.

#### **Print**

Press **CLEAR 3** to PRINT the message. Make sure your printer is properly set in the PRINTER subfunction before you print.

#### **Delete**

To DELETE a message, place the marker over a message listing, and press CLEAR (8). The message is immediately deleted.



# BACKUP PROCEDURES

# Formatting Your Diskettes

Before you back up your diskettes you must format two blank diskettes to use as backups, as follows:

- 1. Turn on your computer.
- 2. Insert a new, blank diskette (or an old diskette you wish to reuse) into Drive 1, and close the drive door.
- 3. Insert a TRSDOS 6.2.0 system diskette into Drive 0, and close the drive door.
- 4. Press the reset buttom.
- 5. The screen shows:

Date MM/DD/YY ?

Type today's date, and press (ENTER).

- 6. At TRSDOS Ready, type **FORMAT :1** (Q = N) **ENTER**.
- 7. If you are reusing an old diskette, the screen may show:

Disk contains data — Name = NAMEAre you sure you want to format it? Date = MM/DD/YY

Type Y, and press (ENTER).

8. When the formatting process is complete, the screen shows:

Formatting complete

TRSDOS Ready

Follow steps 1 - 8 to format a second blank diskette.



#### Backing Up Your Data Diskette

- 1. Insert a TRSDOS 6.2.0 system diskette into Drive 0 and a blank, formatted diskette into Drive 1.
- 2. Type **BACKUP** :0 :1 (X) **ENTER**.

When Insert SOURCE disk <ENTER> appears, remove the system diskette from Drive 0, and insert the Data diskette. Close the drive door, and press (ENTER).

3. The following message may appear on the screen:

Destination disk ID is different: Name = NAME Date = MM/DD/YY

Are you sure you want to backup to it <Y,N>?

Type Y ENTER.

4. When the backup procedure is complete, the screen shows:

Insert SYSTEM disk <ENTER>

Remove the diskette from Drive  $\emptyset$ , and insert the system diskette. Press (ENTER). The screen shows:

Backup complete

TRSDOS Ready

Remove the diskettes. Using a felt-tip pen, write the diskette name on the label of the new backup diskette.

#### Backing up Your Program Diskette

- 1. Insert a TRSDOS system diskette in Drive 0 and a blank, formatted diskette in Drive 1.
- 2. Type **BACKUP** (ENTER).

Remove the system diskette from Drive 0 and insert the Program diskette. Close the drive door.

- Enter 0 as the Source drive number and 1 as the Destination drive number.
- 4. The following message may appear on the screen:

Destination disk ID is different: Name = NAME Date = MM/DD/YY

Are you sure you want to backup to it  $\langle Y, N \rangle$ ?

Type Y (ENTER). When the backup is complete, the screen shows:

Backup complete

TRSDOS Ready

Remove the diskettes. Using a felt-tip pen, write the diskette name on the label of the new backup diskette.

# MODEM INFORMATION

Following are the modem definitions for the 4P, Modem II, DC-1200, and DC-2212.

Note: If you are using a rotary phone, omit T wherever it appears in the definition for your modem. Also, wherever the caret symbol (^) appears, enter this by pressing CLEAR ; on the keyboard. Wherever the backslash (\) appears, enter this by pressing CLEAR ; on the keyboard.

#### 4P (Default Setting)

Computer Dialing		Voice Dialing		Answer Mode	
Press:	Enter:	Press:	Enter:	Press:	Enter:
SEND NUMBER	*C*MG@^DDT	SEND NUMBER	*C*MG@^DDT	SEND RECEIVE	*C*MGAX X
SEND	X	SEND	X		
RECEIVE	X	RECEIVE	X		
WAITNC WAITC		PAUSE	4		

#### Modem II

Computer Dialing		Voice Dialing		Answer Mode		
Press:	Enter:	Press:	Enter:	Press:	Enter:	
SEND NUMBER	**ODT	SEND NUMBER	**ODT	SEND RECEIVE	**C	
SEND	X	SEND	X		1	
RECEIVE WAITNC WAITC	X	RECEIVE WAITNC	X			

#### DC-1200

Computer Dialing		Voice Dialing	Answer Mode	
Press:	Enter:	Not applicable	No definition required — always	
SEND NUMBER	**ODT		in answer mode	
SEND	X			
RECEIVE	ON LINE			

#### DC-2212

Computer Dialing		Voice Dialing		Answer	Mode
Press:	Enter:	Press:	Enter:	Press:	Enter:
SEND RECEIVE NUMBER SEND RECEIVE	*.C*.G@^\DT T X ON LINE ORIG	SEND RECEIVE NUMBER SEND RECEIVE PAUSE SEND RECEIVE	*.C*.G@^\DT T  PPPPX X 4  More * DISCONNECT	SEND RECEIVE	*.C*.G@^\AX AUTO ANSWER  FMAT BE NECESTRY OMLING A LONG NUMBER

# HARD DISK INSTRUCTIONS

This appendix explains how to prepare your hard disk to run DeskMate. Your hard disk should have TRSDOS 6.2.0 installed on it before you proceed.

Follow the instructions below, using backups of the original DeskMate Program and Data Diskettes.

1. Start up or reset the hard disk system (with the START-UP Diskette in floppy Drive 0). The computer then assigns logical numbers to your drives.

When TRSDOS Ready appears, remove the START-UP Diskette and replace it with the DeskMate Program Diskette. (Floppy Drive 0 is now logical Drive 4).

2. First, type BACKUP SYS6/SYS:4:0 (S) ENTER.

When TRSDOS Ready reappears, type **BACKUP**:4:0 (ENTER) to move the DeskMate programs to your hard disk. The BACKUP utility moves the disk files from logical Drive 4 to the hard drive you specified, showing each filename.

3. When the files have been moved, TRSDOS Ready reappears. To move the rest of the DeskMate program, remove the DeskMate Program Diskette form floppy Drive 0 and replace it with the DeskMate Data Diskette. Type BACKUP DM\$/\$:4:0 (ENTER).

Note: If you also wish to move all DeskMate data files to hard Drive 0, you can replace the above BACKUP command with one that will move both the program and data on the DeskMate Data Diskette. Type BACKUP:4:0 (ENTER). To move DeskMate data files to hard Drive 1, see Step 7.

4. You need to enter a few more commands so that DeskMate will be ready to run on your hard disk. If you have not installed your communications driver, you need to do this step. If you have set your communications driver, skip to Step 5.

When TRSDOS Ready reappears, remove the DeskMate Data Diskette from floppy Drive 0 and replace it with the DeskMate Program Diskette. Now type **SET** \***CL TO COM** (ENTER).

- 5. When TRSDOS Ready reappears, type **SET KI** (**W** = **10**, **R** = **1**) (ENTER).
- 6. Before you enter the last command, remove the DeskMate Program Diskette, and replace it with the START-UP Diskette, then type SYSGEN (DRIVE = 4) (ENTER). You can now run DeskMate solely on the hard disk without using floppy diskettes.
- 7. In general, to move DeskMate data files to a hard drive, use the following BACKUP instruction:

#### BACKUP \$/ext:4 :d (ENTER)

ext is the extension of the DeskMate files you want to move, and d is the number of the drive on which you want to store the data files. (\$ tells TRSDOS to copy all files that end with the specified extension.)

Make sure that whatever drive you specify as the drive on which to store data (d) is the same drive the DeskMate program uses for data files. (If you have not used the SWAP function from DeskMate's Main Menu, the program assumes that all data is stored on Drive 1. If you want to store DeskMate data on hard Drive 0, use the SWAP function to designate Drive 0 as the drive on which to store data files.)

For example, to copy all Text files to hard Drive 1, you would type **BACKUP** \$/DOC:4:1 (ENTER).

Use the following extensions to copy the rest of the DeskMate data files:

/WKS for Worksheet files /FIL for Filer files /LOG for Telecom files /CAL for Calendar files /MSG for Mail message files

8. To copy one particular DeskMate data file to a hard disk, use the COPY function on DeskMate's Main Menu.

#### **INDEX**

```
absolute value 49, 50
access, restricting See password
accumulator 9-10
ACODE 11, 12
ADD
   Alarm 19-20, 22
   Calendar 84-85, 92
   Filer 59, 67, 69
   Phone 13
ADD/REPLACE 32, 36
add mode 32, 69
addition 10, 49, 50
adjust printer settings 13-14
Alarm 2, 9, 19-22
    Calendar 90
ALARM ON/OFF 15
ANSWER 76
Answer Mode Definition See ANSWER
applications, list of 1-2
application files 6-7
   creating 6-7
   exiting 7
   opening 6-7
arctangent 49, 50
arrow keys 4, 5
   Alarm 19
    Calendar 86
    Filer 60
    Mail 95
    Text 34
    Worksheet 44
ASCII character filter 73, 79
auto line feed 73
AUTOLOG 77
auto logon sequences 74, 77-78
average 47, 49, 50
backing up diskettes 99-101
BAUD rate 24, 72
BREAK sequence 80
BUFFER 79
buffer, copying See COPY
```

```
CALC 47, 48-49
Calculator 2, 9-10
Calendar 2, 83-92
CALL
   Filer 63
    Phone 12
   Telecom 77, 80
canceling an operation 7
cell 42
CLEAR 79, 81
clear calculator
clear worksheet data See OUTCOMES
column, cumulative sum of 49, 51
combining documents See Merge
command kevs 4
COMP 74-75
Computer Dialing Definition See COMP
constant 50
COPY
    Alarm 22
    Calendar 91
    Filer 68
    Main Menu 30
    Text 38
    Worksheet 55
copying the buffer See COPY
copying diskettes See backing up diskettes
cosine 49, 51
cube 49, 50
cumulative total 49, 51, 52
CREATE 96-97
creating an application file 6-7
Daily Events Calendar 84
DATE 3
    Calendar 89
    Main Menu 18
    subfunctions 15
 day events 3
 DELETE
     Alarm 21, 22
     Calendar 91
     Filer 67, 68
     Mail 97
     Main Menu 30
```

Phone 13 Telecom 75, 76, 78 Text 39 Worksheet 55 dial See CALL dialing sequence 74-75 DIRECTORY OF FILES 25-26 DISC 80 disconnect communication See DISC DISCONNECT FROM HOST 29 diskettes, backing up 99-101 DISPLAY Filer 63-64 Mail 97 Telecom 80 division 10, 49, 50 document file 32 echo 73 edit characters 65 EDITLOG 77-78 entering DeskMate 3 event scheduling See Calendar EXCHANGE 39 exiting an application file 7 exiting DeskMate 7 exponential 49, 51 file efficiency 66 filenames 6-7 Filer 1, 57-69, 75 FIND Calendar 88-89 Filer 62-63 Mail 96 Phone 12 Text 35 Worksheet 48 FORM 58, 64-67 FORMAT Text 36 Worksheet 45, 53-54 formatting diskettes 99 FORMULA 49-52

FREE 18 full duplex 73 function keys 4, 5 half duplex 73 hard disk instructions 105 HELP 8-9 Alarm 19 Calendar 83 Filer 57 Mail 93 Main Menu 17 Telecom 71 Text 31 Worksheet 41 HOST 2, 22-29, 76, 77-78 INSERT Telecom 75, 76, 78 Text 39 Worksheet 56 insert dots 65 integer truncation 49, 51 interactive terminal mode 24, 77, 79-80 label lines 3 subfunctions 8 line feed filter 73 line status 24 LOAD 81 local operation 23-24 logarithm 49, 51 logon sequence 74, 77-78 Mail 2, 93-97 Main Menu 3, 17-30 functions 18-29 MARK 63 maximum value 49, 51 MERGE Alarm 21 Calendar 90 Filer 67-68 Text 36-37 Worksheet 54

minimum value 49, 51 modem 2, 22-23, 71-73, 103-104 Modem Definition 74-76 Month Calendar 3 multiplication 10, 49, 50 NAME 18 negate 10 nested operations 49 NUMBER 66-67, 74 opening an application file 6-7 operand 9, 10 operator 10, 49 ORDER 58, 59, 66 OUTCOMES 56 overstrike mode 84 PACK 66 parity 24, 72 PASSWORD 29 HOST 25, 29 PAUSE 75, 76, 78 percentages 10 PHONE 2, 11-13, 75 powers 49, 50 PREFIX1-3 11, 12-13 PRINT 13 Calendar 89 Filer 64 Mail 97 Phone 13 Telecom 80 Text 34, 35 Worksheet 56 PRINTER 13-14 Telecom 79 priority number 66 pulse rate 24 READ MAIL 27-28 RECEIVE 75, 76, 77, 79 RECEIVE FILE 26-27

reference error 48-49 remote site 22-23, 24-29, 76

111

```
replace mode 32, 36
replacement string 39
RESET
   Calendar 89
    Filer 63
   Telecom 74
retries 73
reverse sign 10
row, cumulative sum of 49, 52
SAVE
    Telecom 81
    Text 37
scheduling events See Calendar
scratchpad 6
SCREEN 13
search string 39
security 23, 25 See also password
SELECT
    Alarm 21
    Calendar 91
    Filer 68
    Main Menu 29
    Telecom 74-76
    Text 37-38
    Worksheet 55
SEND 75, 76, 78, 79-80
SEND FILE 27
SEND MAIL 28
sign of a value 49, 52
sine 49, 52
SORT 13
spreadsheet See worksheet
square root 49, 52
STATUS 77
status settings 71-73
    Host 22-23, 24
    Telecom 71-73
 stop bits 24, 72
 subfunctions 1, 8-15
 subtraction 10, 49, 50
 sum of the values 49, 52
```


#### SWAP 30

tangent 49, 52
Telecom 1, 71-81
telecommunications See Telecom
TERMINAL 24, 77, 79-80
terminal mode See TERMINAL
Text 1, 31-39
Worksheet 45-46, 53
text editor See Text
truncated value 49, 51

VOICE 12, 75
Voice Dialing Definition See VOICE
WAITC 75, 76
WAITNC 75, 76
Weekly Time Chart 84
wildcard
Calendar 88
Filer 62
window 42
window print See PRINT
word length 24, 72
Worksheet 1, 41-56
worksheet 41, 42-43, 45

XON/OFF 72







# RADIO SHACK, A DIVISION OF TANDY CORPORATION

U.S.A.: FORT WORTH, TEXAS 76102 CANADA: BARRIE, ONTARIO L4M 4W5

#### TANDY CORPORATION

AUSTRALIA BELGIUM U. K.

91 KURRAJONG AVENUE PARC INDUSTRIEL BILSTON ROAD WEDNESBURY
MOUNT DRUITT, N.S.W. 2770 5140 NANINNE (NAMUR) WEST MIDLANDS WS10 7JN